

# User Manual UR15 PolyScope X



Original instructions (en)

PolyScope X



The information contained herein is the property of Universal Robots A/S and shall not be reproduced in whole or in part without prior written approval of Universal Robots A/S. The information herein is subject to change without notice and should not be construed as a commitment by Universal Robots A/S. This document is periodically reviewed and revised.

Universal Robots A/S assumes no responsibility for any errors or omissions in this document.

Copyright © 2009-2025 by Universal Robots A/S.

The Universal Robots logo is a registered trademark of Universal Robots A/S.

# 1. Preface

Introduction	Congratulations on the purchase of your new Universal Robots robot, that consists of the robot arm (manipulator), Control Box and the Teach Pendant. Originally designed to mimic the range of motion of a human arm, the robot arm is composed of aluminium tubes, articulated by six joints, allowing for a high range of flexibility in your automation installation. The Universal Robots patented programming interface, PolyScope, allows you to create, load and run your automation applications.
About this manual	<ul> <li>This manual contains safety information, guidelines for safe use, and instructions to mount the robot arm, Control Box and Teach Pendant. You can also find instructions for how to begin to install and how to start programming the robot.</li> <li>Read and adhere to the intended uses. Perform a risk assessment. Install and use in accordance with the electrical and mechanical specifications provided in this user manual.</li> <li>Risk assessment requires an understanding of the hazards, risks and risk reduction measures for the robot application. Robot integration can require a basic level of mechanical and electrical training.</li> </ul>
Content disclaimer	Universal Robots A/S continues to improve the reliability and performance of its products, and as such reserves the right to upgrade products, and product documentation, without prior warning. Universal Robots A/S takes every care to ensure the content of the User Manual/s is precise and correct, but takes no responsibility for any errors or missing information. This manual does not contain warranty information.
Online manuals	<ul> <li>Manuals, guides and handbooks can be read online. We have gathered a large number of documents at <a href="https://www.universal-robots.com/manuals">https://www.universal-robots.com/manuals</a></li> <li>PolyScope Software Handbook with descriptions and instructions for the software</li> <li>The Service Handbook with instructions for troubleshooting, maintenance and repair</li> <li>The Script Directory with scripting for in depth programming</li> </ul>

UR+	The online showroom UR+ <u>www.universal-robots.com/plus</u> provides cutting-edge products to customize your UR robot application. You can find everything you need in one place – from tools and accessories to software.	
	UR+ products connect to and work with UR robots to ensure simple set-up and an overall smooth user experience. All UR+ products are tested by UR.	
	You can also access the UR+ Partner Program via our software platform <u>plus.universal-</u> robots.com to design more user-friendly products for UR robots.	
Academy	The UR Academy site <u>academy.universal-robots.com</u> offers a variety of training opportunities.	
myUR	The myUR portal allows you to register all your robots, keep track of service cases and answer general support questions.	
	Sign into myur.universal-robots.com to access the portal.	
	In the myUR portal, your cases are handled either by your preferred distributor, or escalated to Universal Robots Customer Service teams. You can also subscribe to robot monitoring and manage additional user accounts in your company.	
Developer suite	The UR Developer Suite <u>universal-robots.com/products/ur-developer-suite</u> is a collection of all the tools needed to build an entire solution, including developing URCaps, adapting end-effectors, and integrating hardware.	
Support	The support site <u>www.universal-robots.com/support</u> contains other language versions of this manual	
UR forums	The UR Forum forum.universal-robots.com allows robot enthusiasts of all skill levels to connect to UR and each other, to ask questions and to exchange information. While the U Forum was created by UR+ and our admins are UR employees, the majority of the conten is created by you, the UR Forum user.	



# Contents

1. Preface	6
2. Liability and Intended Use	13
2.1. Limitation of Liability	13
2.2. Intended Use	13
3. Your Robot	
3.1. Technical Specifications UR15	16
3.2. What Is In The Box	17
3.2.1. Robot Arm	17
3.2.2. Control Box	20
3.2.3. Teach Pendant with 3-Position Enabling Device	21
3.2.4. PolyScope X Overview	26
4. Safety	33
4.1. General	33
4.2. Safety Message Types	34
4.3. General Warnings and Cautions	35
4.4. Integration and Responsibility	37
4.5. Stop Categories	
5. Lifting and Handling	
5.1. Robot Arm	40
5.1.1. Round Sling Use	40
5.2. Control Box and Teach Pendant	42
6. Assembly and Mounting	43
6.1. Securing the Robot Arm	44
6.2. Dimensioning the Stand	46
6.3. Mounting Description	48
6.3.1. Control Box Mounting	
6.3.2. Control Box Clearance	51
6.4. Workspace and Operating Space	52
6.4.1. Singularity	53
6.4.2. Fixed and Movable Installation	54
6.5. Robot Connections: Base Flange Cable	55
6.6. Robot Connections: Robot Cable	
6.7. Mains Connections	57
7. First Boot	59
7.1. Powering On the Robot	60
7.2. Inserting the Serial Number	60

7.3. Starting the Robot Arm	61
7.4. Powering Down the Robot	
7.5. Application Tab	
7.5.1. Communication	
8. Installation	65
8.1. Electrical Warnings and Cautions	
8.2. Control Box Connection Ports	
8.3. Ethernet	
8.4. 3PE Teach Pendant Installation	
8.4.1. Hardware Installation	
8.5. Controller I/O	71
8.5.1. Digital Input and Output	
8.5.2. Using the I/O Tab	74
8.5.3. Drive Power Indicator	
8.6. Safety I/O	77
8.6.1. I/O Setup	
8.6.2. Using I/O for Mode Selection	
8.6.3. Three Position Enabling Device	
8.6.4. Safety I/O Signals	
8.7. General Purpose Digital I/O	
8.7.1. Remote ON/OFF control	
8.8. General Purpose Analog I/O	
9. End Effector Integration	
9.1. Maximum Payload	
9.2. Securing Tool	
9.3. Tool I/O	
9.3.1. Tool I/O Installation Specifications	
9.3.2. Tool Power Supply	
9.3.3. Tool Digital Inputs	
9.3.4. Tool Digital Outputs	
9.3.5. Tool Analogue Inputs	105
9.4. Set Payload	
9.4.1. Safely Setting the Active Payload	
10. Configuration	
10.1. Settings	107
10.1.1. Password	
10.1.2. Secure Shell (SSH) Access	
10.1.3. Permissions	
10.1.4. Services	115

# 

10.2. Safety Related Functions and Interfaces	
10.2.1. Configurable Safety Functions	
10.2.2. Safety Function	117
10.3. Safety Configuration	117
10.4. Setting a Safety Password	117
10.5. Safety Menu Settings	117
10.5.1. Robot Limits	
10.5.2. Safety Planes	120
11. Cybersecurity Threat Assessment	
11.1. General Cybersecurity	
11.2. Cybersecurity Requirements	122
11.3. Cybersecurity Hardening Guidelines	124
12. Communication Networks	
12.1. Profinet	
12.2. Ethernet/IP	
12.3. UR Connect	
13. Risk Assessment	134
13.1. Pinch Hazard	
13.2. Stopping Time and Stopping Distance	
14. Emergency Events	
14.1. Emergency Stop	
14.2. Movement Without Drive Power	
14.3. Disassembly of Arm	145
14.4. Operational Mode	148
15. Transportation	
15.1. Teach Pendant Storage	
16. Maintenance and Repair	
16.1. Testing Stopping Performance	
16.2. Robot Arm Cleaning and Inspection	154
17. Disposal and Environment	
18. Declarations and Certifications	
18.1. Declaration of Incorporation (original)	
18.2. Declarations and Certificates	
18.3. Certifications UR15	
18.4. Certificates UR15	
19. Safety Functions Table	
19.1. Table 1a	
19.2. Table 2	



# 2. Liability and Intended Use

# 2.1. Limitation of Liability

#### Description

Any information provided in this manual must not be construed as a warranty, by UR, that the industrial robot will not cause injury or damage, even if the industrial robot complies with all safety instructions and information for use.

# 2.2. Intended Use

## Description



#### NOTICE

Universal Robots takes no responsibility and assumes no liability for unapproved uses of its robots or uses for which its robots are not intended and Universal Robots will provide no support for unintended uses.



#### READ MANUAL

Failure to use the robot in accordance with the intended use can result in hazardous situations.

• Read and follow the recommendations for intended use and the specifications provided in the User Manual.

Universal Robots robots are intended for industrial use, to handle tools/end effectors and fixtures, or to process or transfer components or products.

All UR robots are equipped with safety functions, which are purposely designed to enable collaborative applications, where the robot application operates together with a human. The safety function settings must be set to the appropriate values as determined by the robot application risk assessment.

The robot and Control Box are intended for inside use where, normally, only nonconductive pollution occurs i.e. Pollution degree 2 environments.

Collaborative applications are only intended for non-hazardous applications, where the complete application, including tool/end effector, work piece, obstacles and other machines, is low risk according to the risk assessment of the specific application.



## WARNING

Using UR robots or UR products outside of the intended uses can result in injuries, death and/or property damage. Do not use the UR robot or products for any of the below unintended uses and applications:

- Medical use, i.e. uses relating to disease, injury or disability in humans including the following purposes:
  - Rehabilitation
  - Assessment
  - Compensation or alleviation
  - Diagnostic
  - Treatment
  - Surgical
  - Healthcare
  - · Prosthetics and other aids for the physically impaired
  - · Any use in proximity to patient/s
- Handling, lifting, or transporting people
- Any application requiring compliance with specific hygienic and/or sanitation standards, such as proximity or direct contact with food, beverage, pharmaceutical, and /or cosmetic products.
  - UR joint grease leaks, and can also be released as vapor into the air.
  - UR joint grease is not "food grade".
  - UR robots do not meet any food, National Sanitization Foundation (NSF), Food and Drug Administration (FDA), or hygienic design standards.

Hygienic standards, for example ISO 14159 and EN 1672-2, require a hygiene risk assessment be conducted.

- Any use, or any application, deviating from the intended use, specifications, and certifications of UR robots or UR products.
- Misuse is prohibited as the result could be death, personal injury, and /or property damage

UNIVERSAL ROBOTS EXPRESSLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR ANY PARTICULAR USE.



## WARNING

Failure to consider the added risks due to the reach, payloads, operating torques and speeds associated with robot application, can result in injury or death.

• Your application risk assessment shall include the risks associated with the application's reach, motion, payload and speed of the robot, end effector and workpiece.

# 

# 3. Your Robot

# 3.1. Technical Specifications UR15

Robot type	UR15
Maximum payload	17.5 kg (38.6 lbs)
Reach	1300 mm / 51.2 in
Degrees of freedom	6 rotating joints
Programming	PolyScope 5 GUI on 12" touchscreen
	or PolyScope X GUI on 12" touchscreen
Power consumption (average)	550 W (max.)
	Approx. 350 W using a typical program
Ambient temperature range	0-50 °C with reduced performance from 35 °C and up.
Safety functions	17 sophisticated safety functions.
	PLd Category 3 in accordance with: EN ISO 13849-1.
	Robot arm: IP 65, Control Box: IP 44, Teach Pendant: IP 54
Cleanroom classification	Control Box: ISO Class 4, Teach Pendant: ISO Class T
Pollution degree	2
Humidity	90% non-condensing
Noise	Robot arm: less than 67 dB(A), Control Box: less than 50 dB
I ool I/O ports	2 digital in, 2 digital out, 2 analog in
Tool I/O power supply & voltage	2 A (Dual pin) 0.9 A (Single pin) & 12 V/24 V
Force Torque sensor accuracy	8.3 N
	All wrist joints: Max 300 °/s
Speed	Elbow joint: Max 240 °/s
Deee versetebility	
	$\pm 0.05$ mm / $\pm 0.00$ is in per ISO 9283
	± 360 ° for all joints except Elbow ± 160 °
Footprint	204 mm / 8 in
	Aluminium, PC/ASA plastic, steel
Robot arm weight	40.7 kg
System update frequency	500 Hz
Control Box size (W × H × D)	460 mm x 449 mm x 254mm / 18.2 in x 17.6 in x 10 in
Control Box weight	12 kg / 26.5 lb
Control Box I/O ports	16 digital in, 16 digital out, 2 analog in, 2 analog out
Control Box I/O power supply	24 V/2 A
Communication	MODBUS TCP & EthernetNet/IP adapter, PROFINET,
	USB 2.0, USB 3.0
Control Box power source	100-240 VAC, 47-440 Hz
Short-Circuit Current Rating (SCCR)	200A
TP size (W × H × D)	300 mm x 231 mm x 50 mm
TP weight	1.8 kg / 3.961 lb
TP cable: Teach Pendant to Control Box	4.5 m / 177 in
	High flex (PUR) 3 m/118 in x 12.1 mm
Robot Cable: robot arm to Control Box	High flex (PUR) 6 m/236 in x 12.1 mm
	High flex (PUR) 12 m/472.4 in x 12.1 mm

# 3.2. What Is In The Box

#### In the boxes

# Robot arm

- Control Box
- Teach Pendant or a 3PE Teach Pendant
- Mounting bracket for the Control Box
- Mounting bracket for the 3PE Teach Pendant
- Key for opening the Control Box
- Cable for connecting the robot arm and the Control Box (multiple options available depending on robot size)
- · Mains cable or power cable compatible with your region
- Round sling or lifting sling (depending on robot size)
- Tool cable adapter (depending on robot version)
- This manual

# 3.2.1. Robot Arm

About the<br/>robot armThe Joints, Base and Tool Flange are the main components of the robot arm. The controller<br/>coordinates joint motion to move the robot arm.

Attaching an end effector (tool) to the Tool Flange at the end of the robot arm, allows the robot to manipulate a workpiece. Some tools have a specific purpose beyond manipulating a part, for example, QC inspection, applying adhesives and welding.



The main components of the robot arm.

- Base: where the robot arm is mounted.
- Shoulder and Elbow: make larger movements.
- Wrist 1 and Wrist 2: make finer movements.
- Wrist 3: where the tool is attached to the Tool Flange.

The robot is partly completed machinery, as such a Declaration of Incorporation is provided. A risk assessment is required for each robot application.

# Light Ring

Description

The light ring at the base of the robot arm provides status indication as described in the table below.



## NOTICE

The light ring configuration can be modified and/or disabled by the user. See the Script Directory for further information.



# NOTICE

The color spectrum of the light ring can deviate at maximum ambient temperature.



1	Light ring
2	Base

Color codes

Color	Mode		
	Steady	Flashing slow 0.5Hz	
Red	Robot not moving or in the process of stopping.		
	1. Emergency stop		
	Robot not moving or in the process of stopping.		
Yellow	<ol> <li>Robot stop (previously known as Protective stop)</li> </ol>		
	2. Recovery		
	3. Safeguard stop (all types)		
_	Automatic mode	Automatic mode	
Green	1. Running	<ol> <li>Running at reduced parameters</li> </ol>	
	Manual mode	Robot can be moved by hand	
Blue	Not Automatic, Not being moved	1. Backdrive	
	1. Booting process	2. Freedrive	
	No power available to the robot arm		
OFF	1. Fault		
	2. Violation		
	3. Loading Screen		
	4. System power OFF		

# 3.2.2. Control Box

#### About the Control Box

The Control Box houses the connection ports and Controller Inputs and Outputs (I/O) used in robot arm programs and installations. The connection ports are used for external connections. The I/O are groups of electrical interfaces used for communication and configuration.



## External connections ports.



Input and Output (I/O) groups.

For detailed descriptions of the Control Box connection ports and the Controller I/O, see the Installation.

# 3.2.3. Teach Pendant with 3-Position Enabling Device

**Description** Depending on the robot generation, your Teach Pendant can include a built-in 3PE device. This is called a 3-Position Enabling Teach Pendant (3PE TP). Higher payload robots can only use the 3PE TP.

If you are using a 3PE TP, the buttons are located on the underside of the Teach Pendant, as illustrated below. You can use either button, according to your preference.

If the Teach Pendant is disconnected, you are required to connect and configure an external 3PE device. The 3PE TP functionality extends to the PolyScope interface, where there are additional functions in the Header.



# Overview of TP

## 1. Power button

- 2. Emergency Stop button
- 3. USB port (comes with a dust cover)
- 4. 3PE buttons



**Freedrive** A Freedrive robot symbol is located under each 3PE button, as illustrated below.



# **3PE Teach Pendant Button Functions**

#### Description



## NOTICE

The 3PE buttons are only active in Manual mode. In Automatic mode, robot movement does not require 3PE button action.

The table below describes the functions of the 3PE buttons.

Positi	on	Description	Action
1	Release	There is no pressure on the 3PE button. It is not pressed.	Robot movement is stopped in Manual mode. Power is not removed from the robot arm and the brakes remain released.
2	Light- press (Grip lightly)	There is some pressure on the 3PE button. It is pressed to a middle point.	Allows your program to play when the robot is in Manual mode.
3	Tight- press (Grip tightly)	There is full pressure on the 3PE button. It is pressed all the way down.	Robot movement is stopped in Manual mode. Robot is in 3PE Stop.



Button release

Button press

# 3.2.4. PolyScope X Overview

Overview PolyScope X is the graphical user interface (GUI) installed on the teach pendant that operates the robot arm via touch screen. The PolyScope X interface allows you to create, load, and execute programs.

To view Main Screen

1

1. Tap the 3D icon on the left toolbar.

This gives you a three-dimensional view of the robot arm in X-Y-Z coordinates.

2. To maximize the 3D viewing area, collapse the right drawer using the right toolbar:



Screen

Layout



• Header - in red-border box. Also called system manager. Contains a folder to load, create, and edit programs and access URCaps.

• Left Toolbar - in green-border box. Also called **navigation hub**. Contains icon/fields to select a main screen:

- Hamburger icon
- Application
- Program
- 3D Viewer
- Operator
- **Right Toolbar** in blue-border box. Also called **multitasking panel**. Contains icon/fields to select a multitask screen:
  - Safety overview icon
  - Move
  - Program structure
  - Global Variables
- Footer in yellow-border box. Also called robot control bar.

Contains buttons to control robot state, speed, and program run/play.

ScreenThe main screen and the multitask screen make up the operating screen combination forCombinationsthe robot.

The multitask screen is independent of the main screen so you can do separate tasks. For example, you can configure a program in the main screen while moving the robot arm in the multitask screen. You also can hide the multitask screen if it is not needed.

- Main screen
- Contains fields and options to manage and monitor robot actions.
- Multitask screen

Contains fields and options often relating to the main screen.



Figure 1.1: Main screen and multitask screen

To show/hide the Multitask Screen

- 1. In the right toolbar, tap any field to show the multitask screen.
- The right toolbar expands to the middle of the screen so the multitask screen becomes visible.
- 2. Tap the currently selected field in the right toolbar to hide the multitask screen.

# **Touch Screen**

**Description** The **Teach Pendant touch screen** is optimized for use in industrial environments. Unlike consumer electronics, teach pendant touch screen sensitivity is, by design, more resistant to environmental factors such as:

- Water droplets and/or machine coolant droplets
- Radio wave emissions
- · Other conducted noise from the operating environment

Using the	The touch sensitivity is designed to avoid false selections on PolyScope X and to prevent	
Touch Screen	unexpected motion of the robot.	
For best results, use the tip of your finger to make a selection on the screen. I		
manual/handbook, this is referred to as a <b>tap</b> .		
	A commercially available stylus may be used to make selections on the screen, if desired.	
	The preceding section lists and defines the icons/tabs and buttons in the PolyScope X	
	interface.	

# Icons

# **Header Icon**

lcon	Title	Description
ß	Program name	Gives access to System Manager. Enables you to create, modify, add program, and URCaps files.
Left Toolb	oar Icons	
lcon	Title	Description
	More	Access to information of robot version, serial number, and settings.
	Application	Configures and sets up the robot arm settings and safety, including end effectors and communication.
•••	Program	Access to basic and advanced robot programs.
$\bigcirc$	3D	Enables control and regulation of robot movement in X, Y, Z coordinates.
R	Operator	Operates the robot using prewritten programs and shows the status of the robot.

# Icons Inside the More/Hamburger Icon

lcon	Title	Description
------	-------	-------------

ß	System Manager	Gives access to System Manager. Enables you to create, modify, add program, and URCaps files.
i	About	Displays information about robot version and serial number.
$\langle \! \bigcirc \! \rangle$	Settings	Configures system settings, such as language, units, password, and security.
$\langle 2 \rangle$	Reload	A safe function to apply the default settings defined in the application.
$(\mathbf{b})$	Shutdown	To restart, power on and off the robot.

# **Right Toolbar Icons**

Icon	Title	Description
сс сс сс сс	Safety Overview	Access to the active safety checksum and detailed parameters of each robot arm parts, and changes the operational mode.
¢∱→	Move	Comprehensive function for robot movement, detailing the joints, TCP, flange, base.
∷≡	Program structure	Provides an orderly structure of created program(s). Access to add modules.
{ <i>x</i> }	Global Variables	Access to created program names and values.

# Footer Icons/Buttons

Icon	Title	Description
	Initialize	<ul> <li>Manages the robot state. When RED, press it to make the robot operational.</li> <li>Black, Power off. The robot arm is in a stopped state.</li> <li>Orange, Idle. The robot arm is on, but not ready for normal operation.</li> <li>Orange, Locked. The robot arm is locked.</li> <li>Green, Normal. The robot arm is on and ready for normal operation.</li> </ul>
		<ul> <li>Red, Error. The robot is in a fault state, such as</li> </ul>
IR		<ul><li>e-stop.</li><li>Blue, Transition. The robot is changing state, such as brake releasing.</li></ul>
IR		
	Play	Starts the current loaded program.
	Step	Allows a program to be run single-stepped.
	Stop	Halts the current loaded program.
- Speed +	Speed slider	Manages the robot state. When RED, press it to make the robot operational.
Max 250 mm/s	High Speed Manual	The High Speed Manual slider is only accessible in manual mode when a Three-Position Enabling device is configured. High Speed Manual mode allows tool speed and elbow speed to temporarily exceed the default speed limit.

# Main Screen Icons

lcon	Title	Description
$\uparrow$	Move up	To move up a command node in a program tree.
$\checkmark$	Move down	To move down a command node in a program tree.
9	Revert	To revert a recent move of a command node in a program tree.
5	Undo revert	To undo revert a recent move of a command node in a program tree.
8	Suppress/Unsuppress	To suppress and unsuppress a command node in a program tree.
D	Сору	To copy a command node to another program tree.
	Paste	To paste a command node to another program tree.
*	Cut	To cut a command node from a program tree.
Ŵ	Delete	To delete a command node in a program tree.

# 4. Safety

## Description

Read the safety information here to understand key safety guidelines, important safety messages and your responsibilities when working with the robot. System design and installation are not covered here.

# 4.1. General

#### Description

Read the general safety information and the instructions and guidance pertaining to risk assessment and the intended use. Subsequent sections describe and define safety-related functions particularly relevant for collaborative applications.



#### WARNING

An application risk assessment must be performed for the safety of personnel and equipment.

Read and understand the specific engineering data relevant to mounting and installation, in order to understand the integration of UR robots before the robot is powered on for the first time.

It is essential to observe and follow all assembly instructions in the following sections of this manual.



#### NOTICE

Universal Robots disclaims any and all liability if the robot (arm Control Box with or without Teach Pendant) is damaged, changed or modified in any way. Universal Robots cannot be held responsible for any damages caused to the robot or any other equipment due to programming errors, unauthorized access to the UR robot and its contents, or malfunctioning of the robot.

# 4.2. Safety Message Types

#### Description

Safety messages are used to emphasize important information. Read all the messages to help ensure safety and to prevent injury to personnel and product damage. The safety message types are defined below.



#### WARNING

Indicates a hazardous situation that, if not avoided, can result in death or serious injury.



#### WARNING: ELECTRICITY

Indicates a hazardous electrical situation that, if not avoided, can result in death or serious injury.



#### WARNING: HOT SURFACE

Indicates a hazardous hot surface where injury can result from contact and non-contact proximity.



#### CAUTION

Indicates a hazardous situation that, if not avoided, can result in injury.



#### GROUND

Indicates grounding.



#### **PROTECTIVE GROUND**

Indicates protective grounding.



#### NOTICE

Indicates the risk of damage to equipment and/or information to be noted.



## **READ MANUAL**

Indicates more detailed information that should be consulted in the manual.

# 4.3. General Warnings and Cautions

Description

The following warnings messages can be repeated, explained or detailed in subsequent sections.



# WARNING

Handling tools/end effectors with sharp edges and/or pinch points can result in injury.

- Make sure tools/end effectors have no sharp edges or pinch points.
- Protective gloves and/or protective eyeglasses could be required.



#### WARNING: HOT SURFACE

Prolonged contact with the heat generated by the robot arm and the Control Box, during operation, can lead to discomfort resulting in injury.

- Do not handle or touch the robot while in operation or immediately after operation.
- Check the temperature on the log screen before handling or touching the robot.
- Allow the robot to cool down by powering it off and waiting one hour.



## CAUTION

Failure to perform a risk assessment prior to integration and operation can increase risk of injury.

- Perform a risk assessment and reduce risks prior to operation.
- If determined by the risk assessment, do not enter the range of the robot movement or touch the robot application during operation. Install safeguarding.
- Read the risk assessment information.



## CAUTION

Using the robot with untested external machinery, or in an untested application, can increase the risk of injury to personnel.

- Test all functions and the robot program separately.
- Read the commissioning information.

# NOTICE

Very strong magnetic fields can damage the robot.

• Do not expose the robot to permanent magnetic fields.

# READ

**READ MANUAL** 

Verify all mechanical and electrical equipment is installed according to relevant specifications and warnings.

# 4.4. Integration and Responsibility

# **Description** The information in this manual does not cover designing, installing, integrating and operating a robot application, nor does it cover all peripheral equipment that can influence the safety of the robot application. The robot application must be designed and installed in accordance with the safety requirements set forth in the relevant standards and regulations of the country where the robot is installed.

The person/s integrating the UR robot are responsible for ensuring that the applicable regulations in the country concerned are observed and that any risks in the robot application are adequately reduced. This includes, but is not limited to:

- Performing a risk assessment for the complete robot system
- Interfacing other machines and additional safeguarding if required by the risk
   assessment
- · Setting the correct safety settings in the software
- · Ensuring safety measures are not modified
- Validating the robot application is designed, and installed and integrated
- · Specifying instructions for use
- Marking the robot installation with relevant signs and contact information of the integrator
- Retaining all documentation; including the application risk assessment, this manual and additional relevant documentation.

# 4.5. Stop Categories

# **Description** Depending on the circumstances, the robot can initiate three types of stop categories defined according to IEC 60204-1. These categories are defined in the following table.

Stop Category	Description	
0	Stop the robot by immediate removal of power.	
1	Stop the robot in an orderly, controlled manner. Power is removed once the robot is stopped.	
2	*Stop the robot with power available to the drives, while maintaining the trajectory. Drive power is maintained after the robot is stopped.	

\*Universal Robots robots' Category 2 stops are further described as SS1 or as SS2 type stops according to IEC 61800-5-2.

# 5. Lifting and Handling


	Description	Action	Detail
1	Transport		
2			
3	Opening the b	OX	
5			
6	Removing rob	ot arm from box using strap	
7	Lifting robot ar	m using strap and hook	When releasing and lifting the robot, support it to rotate and hang as illustrated.
8a		a. Normal mounting	<ul> <li>Fasten strap securely when using.</li> </ul>
8b Mounting b. And degree	b. Angular mounting +/-45 degrees	<ul> <li>Remove and store strap when not using.</li> </ul>	
9 10 11	Mounting preparation	Sideways/Upsidedown/Angular mounting >45 degrees	<ol> <li>Remove strap</li> <li>Power on robot and reposition shoulder joint as intended.</li> <li>Skip step 10 for sideways mounting.</li> <li>Replace the strap as illustrated.</li> <li>Move to mounting position.</li> <li>Fasten securely.</li> <li>Remove and store strap.</li> </ol>
12 13 14	Mounting execution	Sideways/Upsidedown/Angular mounting >45 degrees	When releasing and lifting the robot, support it to rotate and hang as illustrated.

#### WARNING

Lifting or movement of heavy parts can cause injury.

- Lifting apparatus/aid to lift can be required.
- Unpack the robot arm in the desired workspace to minimize lifting and movement of heavy parts.



#### WARNING

Incorrect assembly of components and/or wiring can lead to injury.

• Personal protective gear (footwear, eyewear, gloves) can be required.

#### CAUTION

Failure to use an appropriate lifting device for the weight of the robot can lead to injury and property damage.

For UR20 and UR30:

- The lifting device shall be capable of lifting 64 kg robot only.
- The lifting device shall be capable of lifting 84 kg robot with payload.
- For UR15:
  - The lifting device shall be capable of lifting 41 kg robot only.
  - The lifting device shall be capable of lifting 58.5 kg robot with payload.

For UR8 Long:

- The lifting device shall be capable of lifting 44.7kg robot only.
- The lifting device shall be capable of lifting TBD robot with payload.

NOTICE

There may be specific regulations for assembly lifting in your region.

· Follow the local regulations and guidelines for lifting.

For detailed mounting descriptions, see Assembly section.

## 5.1. Robot Arm

Description The robot arm, depending upon weight, can be carried by one or two people unless the sling is provided. If the sling is provided, equipment for lifting and transport is required.

### 5.1.1. Round Sling Use

Description

The round sling is provided by UR with UR15, UR20 and UR30 robots. According to the manufacturer, the round sling conforms to the following standards:

- EN 1492-1 :2000+A1 :2008 Textile slings Safety Flat woven webbing slings, made of man-made fibers, for general purpose use.
- EN 1492-2 :2000+A1 :2008 Textile slings Safety Round slings, made of manmade fibers, for general purpose use.

#### WARNING

Using the round sling without an inspection can lead to injury.

- Inspect the sling before and after each use.
- Inspect the sling during use if possible.

#### WARNING

Using a damaged round sling can result in injury.

- Carefully examine the sling visually before each use.
- Do not use the sling if it is cracked, ripped, or the stitching is loose.
- Do not use the sling if there are signs of heat damage.



Incorrect storage and/or handling can cause damage to the round sling.

- · Keep the sling away from acids and bases.
- Protect the sling against sharp edges and friction.
- Do not tie a knot in the sling.

#### NOTICE

There may be specific regulations for inspecting lifting equipment in your region.

- Observe local regulations regarding inspection of lifting equipment.
- Observe local regulations regarding inspection frequency of lifting equipment.

#### Table

Round Sling Des	cription		
Item	Round sling 1T x 1M/2M		
Color	Violet (according to EN 1492-2)		
Material	Polyester		
W/L Factor	1.0 (1000 KG)	Straight Lift	9
	0.8 (800 KG)	Choke Hitch	8

# 5.2. Control Box and Teach Pendant

**Description** The Control Box and the Teach Pendant can each be carried by one person. While in use, all cables are to be coiled and held to prevent tripping hazards.

# 6. Assembly and Mounting

Description	Install and power on the robot arm and Control Box to start using PolyScope.
Assemble the robot	You have to assemble the robot arm, Control Box and Teach Pendant to be able to continue.
	1. Unpack the robot arm and the Control Box.
	2. Mount the robot arm on a sturdy, vibration-free surface.
	Verify the surface can withstand at least 10 times the full torque of the base joint and at least 5 times the weight of the robot arm.
	3. Place the Control Box on its Foot.
	4. Connect the robot cable to the robot arm and the Control Box.
	5. Plug in the mains, or main power cable, of the Control Box.
	WARNING
	Failure to secure the robot arm to a sturdy surface can lead to injury caused by the robot falling.

• Ensure the robot arm is secured to a sturdy surface

# 6.1. Securing the Robot Arm



To power down the robot arm



Unexpected start-up and/or movement can lead to injury

- Power down the robot arm to prevent unexpected start-up during mounting and dismounting.
- At the left side of the footer, tap the Robot State icon to turn off the robot arm. The icon color changes from green to white.
- 2. Press the power button on the Teach Pendant to turn off the Control Box.
- 3. If a Shutdown dialog box displays, tap Power Off.

At this point, you can continue to:

- Unplug the mains cable / power cord from the wall socket.
- Allow 30 seconds for the robot to discharge any stored energy.

To secure the robot arm	1. 2.	Place the robot arm on the surface on which it is to be mounted. The surface must be even and clean. Tighten the six 8.8 strength, M10 bolts to a torque of 45 Nm. (Torque values have been updated SW 5.18. Earlier printed version will show different values)
	3.	If accurate re-mounting of the robot is required, use the Ø8 mm. hole and Ø8x13 mm. slot with corresponding ISO 2338 Ø8 h6 positioning pins in the mounting plate.

# 6.2. Dimensioning the Stand

**Description** The structure (stand) on which the robot arm is mounted is a crucial part of the robot installation. The stand must be sturdy and free of any vibrations from external sources.

Each robot joint produces a torque that moves and stops the robot arm. During normal uninterrupted operation and during stopping motion, the joint torques are transferred to the robot stand as:

- Mz: Torque around the base z axis.
- Fz: Forces along base z axis.
- Mxy: Tilting torque in any direction of the base xy plane.
- Fxy: Force in any direction in the base xy plane.



Force and moment at base flange definition.

Dimensionin<br/>g the StandThe magnitude of the loads depends on robot model, program and multiple other factors.Dimensioning of the stand shall account for the loads that the robot arm generates during<br/>normal uninterrupted operation and during category 0, 1 and 2 stopping motion.

During stopping motion, the joints are allowed to exceed the maximum nominal operating torque. The load during stopping motion is independent of the stop category type. The values stated in the following tables are maximum nominal loads in worst-case movements multiplied with a safety factor of 2.5. The actual loads will not exceed these values.

Robot Model	Mz [Nm]	Fz[N]	Mxy[Nm]	Fxy [N]
UR15	1310	2430	1730	1720

Maximum joint torques during category 0, 1 and 2 stops.

Robot Model	Mz [Nm]	Fz[N]	Mxy[Nm]	Fxy [N]
UR15	1090	1860	1310	1490
			1	

Maximum joint torques during normal operation.

The normal operating loads can generally be reduced by lowering the acceleration limits of the joints. Actual operating loads are dependent on the application and robot program. You can use URSim to evaluate the expected loads in your specific application.

**Safety** You can incorporate added safety margins, factoring in the following design considerations: **margin** 

- s
- Static stiffness: A stand that is not sufficiently stiff will deflect during robot motion, resulting in the robot arm not hitting the intended waypoint or path. Lack of static stiffness can also result in a poor freedrive teaching experience or protective stops.
- **Dynamic stiffness**: If the frequency of the stand matches the movement frequency of the robot arm, the entire system can resonate, creating the impression that the robot arm is vibrating. Lack of dynamic stiffness can also result in protective stops. The stand should have a minimum resonance frequency of 45 Hz.
- Fatigue: The stand shall be dimensioned to match the expected operating lifetime and load cycles of the complete system.



#### WARNING

- Potential for tip-over Hazards.
  - The robot arm's operational loads can cause movable platforms, such as tables or mobile robots, to tip over, resulting in possible accidents.
  - Prioritize safety by implementing adequate measures to prevent the tipping of movable platforms at all times.



#### CAUTION

• If the robot is mounted on an external axis, the accelerations of this axis must not be too high.

You can let the robot software compensate for the acceleration of external axes by using script command:

set\_base\_acceleration()

• High accelerations can cause the robot to make safety stops.

# 6.3. Mounting Description

#### Description

Robot arm (Base)	Mounted with six M10, strength class 8.8 bolts. The M10 bolts shall be tightened with 45Nm. For accurate base repositioning use two Ø8mm. pins in the position holes.
Tool (Tool Flange)	The four M6 thread holes are for attaching a tool to the robot tool flange. The M6, strength class 8.8 bolts shall be tightened with 8Nm. For accurate tool repositioning, use a pin in the Ø6mm. hole provided.
Control Box	The Control Box can be hung on a wall or placed on the ground.
Teach Pendant	The Teach Pendant is wall mounted or placed onto the Control Box. Verify the cable does not cause tripping hazard. You can buy extra brackets for mounting the Control Box and Teach Pendant.

#### WARNING

Mounting and operating the robot in environments exceeding the recommended IP rating can result in injury.

 Mount the robot in an environment suited to the IP rating. The robot must not be operated in environments that exceed those corresponding to the IP ratings of the robot arm (IP65), Teach Pendant (IP54) and Control Box (IP44)



#### WARNING

Unstable mounting can result in injury.

• Always make sure the robot parts are properly and securely mounted and bolted in place.

## 6.3.1. Control Box Mounting

To mount a CB to a wall

Use the bracket, shown below, included with the robot to mount the Control Box. Mount the bracket to a wall, then hang the Control Box on the bracket via the mounting pegs.





### 6.3.2. Control Box Clearance

**Description** The flow of hot air in the Control Box can result in equipment malfunction. The recommended Control Box clearance is 200 mm on each side for sufficient cool airflow.





#### WARNING

A wet Control Box can cause fatal injury.

- Make sure the Control Box and cables do not come into contact with liquids.
- Place the Control Box (IP44) in an environment suited for the IP rating.

# 6.4. Workspace and Operating Space

Description

The workspace is the range of the fully extended robot arm, horizontally and vertically. The operating space is the location where the robot is expected to function.



#### NOTICE

Disregard for the robot workspace and operating space can result in the damage to property.

It is important to consider the cylindrical volume directly above and directly below the robot base when choosing location to mount the robot. Moving the tool close to the cylindrical volume should be avoided because it causes the joints to move fast even when the tool is moving slowly. This can cause the robot to work inefficiently and can make it difficult to conduct a risk assessment.



#### NOTICE

Moving the tool close to the cylindrical volume can cause the joints to move too fast, leading to loss of functionality and damage to property.

• Do not move the tool close to the cylindrical volume, even when the tool is moving slowly.

The cylindrical volume is both directly above and directly below the robot base. The robot extends 1300 mm from the base joint.



### 6.4.1. Singularity

#### Description

A singularity is a pose that restricts the motion and the ability to position the robot. The robot arm can stop moving or have very sudden and fast movements when approaching and leaving singularity. During placement of robot in the workspace and definition of the operating space, it is important to take into consideration the singularity position detailed below.



#### WARNING

Make sure that robot motion near a singularity does not create hazards to anyone within the range of the robot arm, end effector, and workpiece.

· Set safety limits for the speed and acceleration of the elbow joint.



The following causes singularity in the robot arm:

- Outer workspace limit
- Inner workspace limit
- Wrist alignment

OuterThe singularity occurs because the robot cannot reach far enough or it reaches outside ofworkspacethe maximum working area.limit

To avoid: Arrange the equipment around the robot to avoid it reaching outside of the recommended workspace.

Inner workspace limit	The singularity occurs because the movements are directly above or directly below the robot base. This causes many positions/orientations to be unreachable.
	To avoid: Program the robot task in such a way that it is not necessary to work in or close to the central cylinder. You can also consider mounting the robot base on a horizontal surface to rotate the central cylinder from a vertical to horizontal orientation, potentially moving it away from the critical areas of the task.
Wrist alignment	This singularity occurs because wrist joint 2 rotates on the same plane as the shoulder, elbow and wrist joint 1. This limits the range of movement of the robot arm, regardless of workspace.
	To avoid:Layout the robot task in such a way that it is not necessary to align the robot wrist joints in this manner. You can also offset the direction of the tool, so that the tool can point horizontally without the problematic wrist alignment.
6.4.2. Fixe	d and Movable Installation
Description	Whether the robot arm is fixed (mounted to a stand, wall or floor) or in a movable installation (linear axis, push cart, or mobile robot base), it must be installed securely to

The design of the mounting must ensure stability when there are movements of:

- the robot arm
- the robot base
- both robot arm and robot base

ensure stability through all motions.

# 6.5. Robot Connections: Base Flange Cable

**Description** This subsection describes the connection for a robot arm configured with a Base Flange Cable connector.

Base FlangeThe Base Flange Cable establishes the robot connection to the robot arm to the ControlCableBox. The Robot Cable connects to the Base Flange Cable connector on one end, and to the<br/>Control Box connector on the other end.Control Box connectorControl Box connector on the other end.

You can lock each connector when robot connection is established.



#### CAUTION

Improper robot connection can result in loss of power to the robot arm.

• Do not use one Robot Cable to extend another Robot Cable.



#### NOTICE

Connecting the Base Flange Cable directly to any Control Box can result in equipment or property damage.

• Do not connect the Base Flange Cable directly to the Control Box.

# 6.6. Robot Connections: Robot Cable

Description	This subsection describes the connection for a robot arm configured with a fixed 6 meter Robot Cable.
To connect the arm and Control box	<ul> <li>You can turn the connector to the right to make it easier to lock after the cable is plugged in.</li> <li>Establish the robot connection by connecting the robot arm to the Control Box with the Robot Cable.</li> <li>Plug and lock the cable from the robot into the connector at the bottom of the Control Box shown below.</li> <li>Twist the connector twice to ensure it is properly locked before turning on the robot arm.</li> </ul>





#### CAUTION

Improper robot connection can result in loss of power to the robot arm.

- Do not disconnect the Robot Cable when the robot arm is turned on.
- Do not extend or modify the original Robot Cable.

# 6.7. Mains Connections

Description The mains cable to the Control Box has a standard IEC plug at the end.
 NOTICE

 IEC 61000-6-4:Chapter 1 scope: "This part of IEC 61000 for emission requirement applies to electrical and electronic equipment intended for use within the environment of existing at industrial (3.1.12) locations."
 IEC 61000-6-4:Chapter 3.1.12 industrial location: "Locations characterized by a separate power network, supplied from a

of the installation"

#### Mains connections

To power the robot, the Control Box shall be connected to the mains via the supplied power cord. The IEC C13 connecter on the power cord connects to the IEC C14 appliance inlet at the bottom of the Control Box.



#### WARNING: ELECTRICITY

Failure to correctly place the mains connection can result in injury.

• The power plug for the mains connection shall be placed outside the reach of the robot, such that power can be removed without exposing personnel to potential hazards.

high- or medium-voltage transformer, dedicated for the supply

• If additional safeguarding is implemented, the power plug for the mains connection shall also be placed outside the safeguarded space such that power can be removed without exposure to any potential hazards.



#### NOTICE

Always use a power cord with a country specific wall plug when connecting to the Control Box. Do not use an adapter.

As a part of the electrical installation, provide the following:

- Connection to ground
- Main fuse
- Residual current device
- A lockable (in the OFF position) switch

A main switch shall be installed to power off all equipment in the robot application as an easy means for lockout. The electrical specifications are shown in the table below.

Parameter	Min	Тур	Max	Unit
Input voltage	90	-	264	VAC
External mains fuse (90-200V)		-	16	А
External mains fuse (200-264V)	8	-	16	А
Input frequency	47	-	440	Hz
Stand-by power	-	-	<1.5	W
Nominal operating power	90			W



#### WARNING: ELECTRICITY

Failure to follow any of the below can result in serious injury or death due to electrical hazards.

- Ensure the robot is grounded correctly (electrical connection to ground). Use the unused bolts associated with grounding symbols inside the Control Box to create common grounding of all equipment in the system. The grounding conductor shall have at least the current rating of the highest current in the system.
- Ensure the input power to the Control Box is protected with a Residual Current Device (RCD) and a correct fuse.
- Lockout all power for the complete robot installation during service.
- Ensure other equipment shall not supply power to the robot I/O when the robot is locked out.
- Ensure all cables are connected correctly before the Control Box is powered. Always use the original power cord.

# 7. First Boot

Description

The first boot is the initial sequence of actions you can take with the robot after assembly. This initial sequence requires you to:

- Power on the robot
- Insert the serial number
- · Initialize the robot arm
- Power down the robot



#### CAUTION

Failure to verify the payload and installation before starting up the robot arm can lead to injury to personnel and/or property damage.

• Always verify the actual payload and installation are correct before starting up the robot arm.

 $\underline{\mathbb{V}}$ 

#### CAUTION

Incorrect payload and installation settings prevent the robot arm and Control Box in functioning correctly.

• Always verify the payload and installation setting are correct.

#### NOTICE

Starting up the robot in lower temperature can result in lower performance, or stops, due to temperature-dependent oil and grease viscosity.

• Starting up the robot in low temperatures can require a warmup phase.

# 7.1. Powering On the Robot

To power	Powering on the robot turns on the Control Box and loads the display on the TP screen.
on the robot	1. Press the power button on the Teach Pendant to power on the robot.

# 7.2. Inserting the Serial Number

# To insert theInstalling your robot for the first time requires you to enter the serial number on the robot arm.serialThis procedure is also required when you re-install the software. For example, when younumberinstall a software update.

- 1. Select your Control Box.
- 2. Add the serial number as it is written on the robot arm.
- 3. Tap OK to end.

It can take a few minutes for the start screen to load.

Select Control Box	Enter Serial Number	
Standard		
OEM AC	1 2 3 🗵	
OEM DC	4 5 6	
	7 8 9	

# 7.3. Starting the Robot Arm

To startStarting the robot arm disengages the braking system, allowing you to start moving the robotthe robotarm and to start using PolyScope X.

- 1. In the left side of the footer, tap the power button or **Robot State** icon. The robot arm state is **Off**.
- 2. When the Initialize box displays, tap **Power On**. The robot arm state is **Booting**.

obot arm is currently off a	nd not comr	nunicating with the controller
ress <b>"Power On"</b> to send p	ower to the	arm in a locked state.
Active Payload 0.000 kg	Ø	Application Payload   0 kg
		() Power On

3. Tap Unlock to release the brakes.

Arm - LOCKED		
he robot arm is power	ed but for safety h	nas its brakes applied.
Confirm that the below	payload is accura	te before unlocking.
Active Payload 0.000 kg	Ø	Application Payload   0 kg
	(U) Power	r Off
Robot State		
Locked		

Robot arm initialization is accompanied by sound and slight movements as the joint brakes are released.

4. The robot arm state is now Active, and you can start to use the interface.

#### Initialize

Arm - ACTIVE								
Robot arm is currently active and can communicate with the control box and other equipment.								
Press "Power Off" to stop robot arm.	the commun	ication and power off the						
Active Payload 0.000 kg	Ø	Application Payload   0 kg						
		() Power Off						
Robot State Active	<b>⊳</b>							

5. You can tap Power Off to turn off the robot arm.

When the robot arm state changes from **Idle** to **Normal**, sensor data is checked against the configured mounting of the robot arm.

If the mounting is verified, tap **START** to continue releasing all joint brakes, preparing the robot arm for operation.

# 7.4. Powering Down the Robot

To power down the robot arm



#### WARNING

Unexpected start-up and/or movement can lead to injury

- Power down the robot arm to prevent unexpected start-up during mounting and dismounting.
- 1. At the left side of the footer, tap the Robot State icon to turn off the robot arm.

The icon color changes from green to white.

- 2. Press the power button on the Teach Pendant to turn off the Control Box.
- 3. If a Shutdown dialog box displays, tap Power Off.

At this point, you can continue to:

- Unplug the mains cable / power cord from the wall socket.
- Allow 30 seconds for the robot to discharge any stored energy.

# 7.5. Application Tab

#### The Application menu allows you to configure the settings which affect the overall performance of the robot and PolyScope X. Program P CC CC Application 88 •ु• Move J Î//// 60 90 30 Grids {x} Q Global Variable (Q)()Smart Skills Communication Operator Scree \_ ≡ System Info (k) = Max -1000.00 mm/s Speed

Figure 1.1: Application screen displaying application buttons.

Use the Application menu to access to the following configuration screens:

- Mounting
- Frames
- Grids
- End Effectors
- Motion Profiles
- Communication
- Safety
- Smart Skills
- Sidebar
- Operator Screen
- System Info

## 7.5.1. Communication

#### Description

The Communication screen allows you to monitor and set the live I/O signals from/to the robot control box. The screen displays the current state of the I/O, including during program execution. If anything is changed during program execution, the program stops. At program stop, all output signals retain their states.

The Communication screen updates at 10Hz, so very fast signals may not display properly. You can reserve configurable I/Os for special safety settings defined in Safety I/O signals. Those which are reserved will have the name of the safety function in place of the default or user defined name. Configurable outputs reserved for safety settings cannot be selected, they are displayed as LEDs only.



Figure 1.2: Communication screen displaying I/Os.

# 8. Installation

**Description** Installing the robot can require the configuration and use of input and output signals (I/Os). These different types of I/Os and their uses are described in the following sections.

# 8.1. Electrical Warnings and Cautions

#### Warnings

Observe the following warnings for all the interface groups, including when you design and install an application.

#### WARNING

Failure to follow any of the below can result in serious injury or death, as the safety functions could be overridden.

- Never connect safety signals to a PLC that is not a safety PLC with the correct safety level. It is important to keep safety interface signals separated from the normal I/O interface signals.
- All safety-related signals shall be constructed redundantly (two independent channels).
- Keep the two independent channels separate so a single fault cannot lead to loss of the safety function.



#### WARNING: ELECTRICITY

Failure to follow any of the below can result in serious injury or death due to electrical hazards.

- Make sure all equipment not rated for water exposure remain dry. If water is allowed to enter the product, lockout-tagout all power and then contact your local Universal Robots service provider for assistance.
- Only use the original cables supplied with the robot only. Do not use the robot for applications where the cables are subject to flexing.
- Use caution when installing interface cables to the robot I/O. The metal plate in the bottom is intended for interface cables and connectors. Remove the plate before drilling holes. Make sure that all shavings are removed before reinstalling the plate. Remember to use correct gland sizes.

#### CAUTION

Disturbing signals with levels higher than those defined in the specific IEC standards can cause unexpected behaviors from the robot. Be aware of the following:

- The robot has been tested according to international IEC standards for ElectroMagnetic Compatibility (EMC). Very high signal levels or excessive exposure can damage the robot permanently. EMC problems are found to happen usually in welding processes and are normally prompted by error messages in the log. Universal Robots cannot be held responsible for any damages caused by EMC problems.
- I/O cables going from the Control Box to other machinery and factory equipment may not be longer than 30m, unless additional tests are performed.



#### GROUND

Negative connections are referred to as Ground (GND) and are connected to the casing of the robot and the Control Box. All mentioned GND connections are only for powering and signalling. For PE (Protective Earth) use the M6-size screw connections marked with earth symbols inside the Control Box. The grounding conductor shall have at least the current rating of the highest current in the system.



#### **READ MANUAL**

Some I/Os inside the Control Box can be configured for either normal or safetyrelated I/O. Read and understand the complete Electrical Interface chapter.

# 8.2. Control Box Connection Ports

Description	The underside of the I/O interface groups in the Control Box is equipped with external connection ports and a fuse, described below. There are capped openings at the base of the Control Box cabinet to run external connector cables to access the connection ports.									
External connection ports	<ul> <li>The ports for external connections are as follows:</li> <li>Teach Pendant port to use the Teach Pendant to control or program the robot arm.</li> <li>SD card port to insert an SD card.</li> <li>Ethernet port to allow ethernet type connections.</li> <li>Mini DisplayPort to support monitors using DisplayPort. This requires an active Min Display to a DVI or HDMI converter. Passive converters do not work with DVI/HDMI ports.</li> <li>The Mini Blade Fuse is used when an external power supply is connected.</li> </ul>									
	Teach Pendant       SD card       Ethernet       USB 2.0       USB 3.0 Mini DisplayPort       10 A Mini Blade 									
	<ul> <li>NOTICE</li> <li>Connecting or disconnecting a Teach Pendant while the Control Box is powered on can cause equipment damage .</li> <li>Do not connect a Teach Pendant while the Control Box is on.</li> <li>Power off the Control Box before you connect a Teach Pendant.</li> </ul>									
	<ul> <li>NOTICE         Failure to plug in the active adapter before powering on the Control Box can hinder the display output.         Plug in the active adapter before powering on the Control Box.         In some cases the external monitor must be powered on before the Control Box.         Use an active adapter that supports revision 1.2 as not all adapter function out-of-the-box.     </li> </ul>									

# 8.3. Ethernet

Description

The Ethernet interface can be used for:

- MODBUS, EtherNet/IP and PROFINET.
- Remote access and control.

To connect the Ethernet cable by passing it through the hole at the base of the Control Box, and plugging it into the Ethernet port on the underside of the bracket.

Replace the cap at the base of the Control Box with an appropriate cable gland to connect the cable to the Ethernet port.



The electrical specifications are shown in the table below.

Parameter	Min	Тур	Max	Unit
Communication speed	10	-	1000	Mb/s

To remove a

**Teach Pendant** 

# 8.4. 3PE Teach Pendant Installation

#### 8.4.1. Hardware Installation



To remove the standard Teach Pendant:

- 1. Power down the control box and disconnect the main power cable from the power source.
- 2. Remove and discard the two cable ties used for mounting the Teach Pendant cables.
- 3. Press in the clips on both sides of the Teach Pendant plug as illustrated, and pull down to disconnect from the Teach Pendant port.
- 4. Fully open/loosen the plastic grommet at the bottom of the control box and remove the Teach Pendant plug and cable.
- 5. Gently remove the Teach Pendant cable and Teach Pendant.





To install a 3PE Teach Pendant

- 1. Place the Teach Pendant plug and cable in through the bottom of the control box and fully close/tighten the plastic grommet.
- 2. Push the Teach Pendant plug into the Teach Pendant port to connect.
- 3. Use two new cable ties to mount the Teach Pendant cables.
- 4. Connect the main power cable to the power source and power on the control box.

There is always a length of cable with the Teach Pendant that can present a tripping hazard if it is not stored properly.

• Always store the Teach Pendant and the cable properly to avoid tripping hazards.

# 8.5. Controller I/O

#### Description

The electrical interface inside the Control Box consists of groups Inputs and Outputs I/Othat allow for communication and configurations between the robot arm and different types of equipment. The I/O groups include:

- Digital (24V)
- Configurable (24V)
- Analog
- Safety (24V)

The illustration below shows the layout of electrical interface groups inside the Control Box. Observe and maintain the purpose of the color scheme, as illustrated below.

	5	afe	ety	Re	emo	te	Р	owe	r	Conf	igura	ble Inp	outs	Conf	gural	ole Out	puts	Digita	I Input	s	Dig	gital	Output	s		Anal	og
top	24	4V	7	12	V		ΡW	/R		24V		<mark>24</mark> V		0V		0V		24V 🔳	24V		0V		0V		uts	AG	
Jcy S	Ε	10		G١	ID		GΝ	ID		CI0		CI4		coo		CO4		D10 🔳	DI4		D00		D04		l n p	A10	
rger	24	4V		0	N		24	v	5)	24V		24V		0V		0V		24V 🔳	24V		0V		0V		alog	AG	
Eme	Ε	11		01	F		0	v I		CI1		CI5		CO:		CO5		DI1 🔳	DI5		D01		D05		An	AI1	
do	24	4V	2							24V		24V		0V		0V		24V 🔳	24V		0V		0V		uts	AG	
rd St	S	10		-	0	6	m	>	~	CI2		CI6		CO2		COG		D12 🔳	DI6		D02		D06		Outp	A00	
edua	24	4V	7	DI1	DIJ	ā	Ĩ	24	6	24V		24V		0V		0V		24V 🔳	24V		0V		0V		[og	AG	
Safe	S	11								CI3		CI7		CO		C07		DI3 🔳	DI7		DO3		D07		Ana	A01	

Yellow with red text	Dedicated safety signals
Yellow with black text	Configurable for safety
Gray with black text	General purpose digital I/O
Green with black text	General purpose analog I/O

- **I/O groups** You can install the robot according to the electrical specifications which are the same for all three listed inputs.
  - Safety I/O.
  - Configurable I/O.
  - General purpose I/O.



#### NOTICE

Configurable I/O are I/O configured as either safety-related I/O or normal I/O. These are the yellow terminals with black text.

It is possible to power the digital I/O from an internal 24V power supply or from an external power source by configuring the terminal block called **Power**. This block consists of four terminals. The upper two (PWR and GND) are 24V and ground from the internal 24V supply. The lower two terminals (24V and 0V) in the block are the 24V input to supply the I/O. The default configuration uses the internal power supply.

**Power supply** In this example the default configuration uses the internal power supply **default** 



# External powerIf more current is needed, you can connect an external power supply as shown below.supplyThe fuse is Mini Blade type with maximum current rating of 10 A and a minimum voltage<br/>rating of 32 V. The fuse must be UL marked. If the fuse is overloaded, it must be replaced.



In this example the configuration uses an external power supply for more current.

Power supplyThe electrical specifications for both the internal and external power supply are shownspecificationbelow.

Terminals	Parameter	Min	Тур	Max	Unit
Internal 24V power					
supply					
[PWR - GND]	Voltage	23	24	25	V
[PWR - GND]	Current	0	-	2*	A
External 24V input					
requirements					
[24V - 0V]	Voltage	20	24	29	V
[24V - 0V]	Current	0	-	6	A
*2 EA for E00ma or 220/	duty avala				

\*3.5A for 500ms or 33% duty cycle.

# Digital I/OThe digital I/O are constructed in compliance with IEC 61131-2. The electricalspecificationspecifications are shown below.

Terminals	Parameter	Min	Тур	Max	Unit
Digital Outputs					
[COx / DOx]	Current*	0	-	1	А
[COx / DOx]	Voltage drop	0	-	0.5	V
[COx / DOx]	Leakage current	0	-	0.1	mA
[COx / DOx]	Function	-	PNP	-	Туре
[COx / DOx]	IEC 61131-2	-	1A	-	Туре
Digital Inputs					
[EIX/SIX/CIX/DIX]	Voltage	-3	-	30	V
[EIX/SIX/CIX/DIX]	OFF region	-3	-	5	V
[EIX/SIX/CIX/DIX]	ON region	11	-	30	V
[EIX/SIX/CIX/DIX]	Current (11-30V)	2	-	15	mA
[EIX/SIX/CIX/DIX]	Function	-	PNP +	-	Туре
[EIx/SIx/CIx/DIx]	IEC 61131-2	-	3	-	Туре

\*For resistive loads or inductive loads of maximum 1H.

### 8.5.1. Digital Input and Output

# Tool OutputThe tool communication interface allows two digital outputs to be independently configured.<br/>In PolyScope X, each pin has a drop-down menu that allows the output mode to be set. The<br/>following options are available:

The tool output contains two digital output fields, tool output voltage and power supply fields and Dual Pin Power button.

- Digital Output (DO) can be independently set to high or low
- **Tool Output Voltage** range from 4 to 20mA. This setting is persistent over restarts of the robot controller
- Power Supply current can be set between 0-600mA
- **Dual Pin Power** used as a source of power for the tool. Enabling Dual Pin Power disables the default tool digital outputs (DO)

After selecting a new output configuration, the changes take effect. The currently loaded installation is modified to reflect the new configuration. After verifying the tool outputs are working as intended, make sure to save the installation to prevent losing changes.

**Digital Input** You can use the horizontal Digital Inputs block (DI8-DI11), illustrated below, for quadrature encoding Conveyor Tracking.



## 8.5.2. Using the I/O Tab

Description	Use the Wired Box.	Jse the Wired I/O Tab screen to monitor and set the live I/O signals from/to the Control Box.									
	The screen displays the current state of the I/O, including during program execution. The program stops if anything is changed during execution. At program stop, all output signals retain their states. The screen updates at 10Hz, so a very fast signal might not display properly.										
	Communication										
	Robot	Configurable Input	Configurable Output	Digital Input	Digital Output Analog Input Analog Outp		Analog Output				
	Wired ID Program	CI 0 LO CI 4 LO	CO 0 0 CO 4 0	DI 0 LO DI 4 LO	DO 0 10 DO 4 10	ALO	AO 0 4.00 mA				
	Tool IO	Safeguard Reset CI 5 LO	CO 1 LO CO 5 LO	DI 1 10 DI 5 10	DO 1 LO DO 5 LO	0.00 mA 4 CURRENT 20	4 CURRENT 20				
	20 V Modbus	CI 1 LO CI 6 LO	CO 2 LO CO 6 LO	DI 2 LO DI 6 LO	DO 2 LO DO 6 LO	AI 1	AO 1 4.00 mA				
	+ Add Source	CI 2 LO CI 7 LO	CO 3 LO CO 7 LO	DI 3 10 DI 7 10	DO 3 LO DO 7 LO	0.00 mA	4 CURRENT 20				
	Operator	CI3 0									
Configurable	Configurable I	/Os can be res	erved for spe	ecial safety s	ettings defin	ed in the I/C	) Setup				

Configurable I/Os can be reserved for special safety settings defined in the I/O Setup under Safety I/O. Under those which are reserved will have the name of the safety function in place of the default or user defined name. Configurable inputs that are reserved for safety settings are not togglable and will be displayed as LED's only.
 Digital I/Os All eight DIs are set independently to either high or low.
 Analog IOs The analog I/O's can be set to 4-20mA. These settings are persistent over restarts of the robot controller and saved in the installation.
# 8.5.3. Drive Power Indicator

Description	The drive power indicator is a light that turns on when the robot arm is powered on, or when there is power to the robot cable. When the robot arm is powered off, the drive power indicator turns off.
	and does not use safety I/Os.
Indicator	The drive power indicator can be a light that can work at 24VDC.
To set up the	Setting up the indicator requires a light and wiring for the outputs.
indicator	<ol> <li>Connect your drive power indicator to the Digital Outputs as shown in the image below.</li> </ol>
	2. Verify the drive power indicator is correctly connected.
	<ul> <li>You can power on the robot arm and verify the light turns on.</li> </ul>

- You can power off the robot arm and verify the light turns off.



Drive Power Indicator

To configure the indicator

- 1. In the Navigation menu, tap Application.
- 2. Select Communication.
- 3. In the side menu, select Wired IO.
- 4. Scroll to your desired output type and tap to select one of the following:
  - Configurable Output
  - Digital Output
  - Analog Output
- 5. Select Action Preset

You can name the selected output

6. In the dropdown select High when drive power is on, otherwise Low.

≡		Program nam Default pro	ne ogram		P
88	← Communication				CC CC CC CC
Application	V Robot	Configurable Input	Configurable Output	Digital Input	<b>←</b> ‡→ Move
Program	Wired IO	CI 0 LO CI 4 LO	CO 0 LO CO 4 LO	DI 0 LO DI 4 LO	==
$\heartsuit$	Tool IO	CI 5 LO	High when drive power CO 5 LO	DI 1 LO DI 5 LO	Program structure
3D	✓ Modbus	Safeguard Reset	CO 1 LO CO 6 LO	DI 2 LO DI 6 LO	{x}
Q Operator	+ Add Source	CI 2 LO CI 7 LO		DI 3 LO DI 7 LO	Global Variables
		CI 3 LO			
(IR)	Robot State Active		0	Speed 100 %	+
≡		Program nam	ne ogram		<i>®</i> 2
	← Communication				CC CC CC CC
Application		Configurable Input	Configurable Output	Digital Input	¢‡⇒
Program	∨ Robot	CI 0 LO CI 4 LO	CO 0 LO CO 4 LO	DIO LO DI4 LO	Move
$\bigotimes$	Wired IO Tool IO	Safeguard Reset		DI 1 LO DI 5 LO	Program
3D	✓ Modbus	CI 1 LO CO 0 C Safeguard Reset	LO	DI 2 LO DI 6 LO	structure
2	+ Add Source	CI 2 LO C Action Preset		DI 3 LO DI 7 LO	{X} Global Variables
Operator		CI 3 LO	e power is on, otherwise Low		
	Robot State			Speed	Ŧ
				400 %	

# 8.6. Safety I/O

Safety I/O This section describes dedicated safety input (Yellow terminal with red text) and configurable I/O (Yellow terminals with black text) when configured as safety I/O. Safety devices and equipment must be installed according to the safety instructions and the risk assessment in chapter Safety.

All safety I/O are paired (redundant), so a single fault does not cause loss of the safety function. However, the safety I/O must be kept as two separate branches.

The permanent safety input types are:

- Robot Emergency Stop for emergency stop equipment only
- Safeguard Stop for protective devices
- **3PE Stop** for protective devices

#### **Table**The functional difference is shown below.

	Emergency Stop	Safeguard Stop	3PE Stop
Robot stops moving	Yes	Yes	Yes
Program execution	Pauses	Pauses	Pauses
Drive power	Off	On	On
Reset	Manual	Automatic or manual	Automatic or manual
Frequency of use	Infrequent	Every cycle to infrequent	Every cycle to infrequent
Requires re-initialization	Brake release only	No	No
Stop Category (IEC 60204-1)	1	2	2
Performance level of monitoring function (ISO 13849-1)	PLd	PLd	PLd

Safety caution

Use the configurable I/O to set up additional safety I/O functionality, e.g. Emergency Stop Output. Use the PolyScope interface to define a set of configurable I/O for safety functions.



### CAUTION

Failure to verify and test the safety functions regularly can lead to hazardous situations.

- Safety functions shall be verified before putting the robot into operation.
- Safety functions shall be tested regularly.

OSSD All configured and permanent safety inputs are filtered to allow the use of OSSD safety signals equipment with pulse lengths under 3ms. The safety input is sampled every millisecond and the state of the input is determined by the most frequently seen input signal over the last 7 milliseconds.

OSSD	You can configure the Control Box to output OSSD pulses when a safety output is
Safety	inactive/high. OSSD pulses detect the ability of the Control Box to make safety outputs
Signals	active/low. When OSSD pulses are enabled for an output, a 1ms low pulse is generated on
	the safety output once every 32ms. The safety system detects when an output is connected
	to a supply and shuts down the robot.

The illustration below shows: the time between pulses on a channel (32ms), the pulse length (1ms) and the time from a pulse on one channel to a pulse on the other channel (18ms)



To enable OSSD for Safety Output

- 1. In the Header, tap Installation and select Safety.
- 2. Under Safety, select I/O.
- 3. On the I/O screen, under Output Signal, select the desired OSSD checkbox. You must assign the output signal to enable the OSSD checkboxes.

Safety

**FI0** 

FI1

**Default safety** The robot is delivered with a default configuration, which enables operation without any additional safety equipment.

Connecting emergency stop buttons Most applications require one or more extra emergency stop buttons. The illustration below shows how one or more emergency stop buttons can be connected.

Emergency Stop

ol<mark>S</mark> SI0

Safeguard



UR15 PolyScope X

Sharing the Emergency Stop with other machines

You can set up a shared emergency stop function between the robot and other machines by configuring the following I/O functions via the GUI. The Robot Emergency Stop Input cannot be used for sharing purposes. If more than two UR robots or other machines need to be connected, a safety PLC must be used to control the emergency stop signals.

- Configurable input pair: External Emergency Stop.
- · Configurable output pair: System Stop.

The illustration below shows how two UR robots share their emergency stop functions. In this example the configured I/Os used are CI0-CI1 and CO0-CO1.



### Safeguard stop with automatic resume

This configuration is only intended for applications where the operator cannot go through the door and close it behind him. The configurable I/O is used to setup a reset button outside the door to reactivate robot motion. The robot resumes movement automatically when the signal is re-established.



#### WARNING

Do not use this configuration if signal can be re-established from the inside of the safety perimeter.



safeguard device where the robot is stopped when the door is opened.

In this example a door switch is a basic In this example a safety mat is a safety device where automatic resume is appropriate. This example is also valid for a safety laser scanner. Safeguard Stop with reset button If the safeguard interface is used to interact with a light curtain, a reset outside the safety perimeter is required. The reset button must be a two channel type. In this example the I/O configured for reset is CI0-CI1.



# 8.6.1. I/O Setup

#### Description

Use the Safety I/O sub menu to define I/O signals and configure actions with the I/O tab control. The types of I/O signals are listed under **Inputs** and **Outputs**. Use the fields on the main screen to select a function to define.

			Robo			Ţ
	🤶 Safety				Apply 🖻 Lock	30 30 30 30
Application	Robot Limits	Wired Outputs	Signal		0550	+∱+ ↓ Move
Program	✓ Joint Limits Joint Speeds	Function Unassigned	CO 0 CO 1			
3D	Joint Positions	Function Unassigned	✓ CO 2 CO 3			Program structure
Q Operator	Sarety 1/0	Function Unassigned	CO 4 CO 5			{x} Global Variables
	Outputs	Function Unassigned	<ul> <li>CO 6</li> <li>CO 7</li> </ul>			
	Planes Hardware					
	Three Position			b		
	tobot State Dff		$\mathbf{O} \mathbf{O} \mathbf{O}$	-10	Max 00.00 mm/s Speed 100 %	+



### NOTICE

When starting programs from an I/O or fieldbus input, the robot can begin movement from the position it has, there will not be any manual movement to the first waypoint via PolyScope required.

### Safeguard Reset

To limit the number of signals listed under **Input** and **Output**, use the **View** drop-down menu to change the displayed content based on signal type.

Assigning User-defined Names	<ul> <li>You can name the Input and Output signals to easily identify the ones being used.</li> <li>Select the desired signal.</li> <li>Tap the text field to type a name for the signal.</li> <li>To reset the name to default, tap Clear.</li> <li>You must provide a user-defined name for a general purpose register to make it available in the program (i.e., for a Wait command or the conditional expression of an If command). The Wait and If commands are described in (Wait) and (If), respectively. You can find named general purpose registers in the Input or Output selector on the Expression Editor screen.</li> </ul>			
I/O Actions and I/O Tab Control	You can use Phy program.	sical and Fieldbus digital I/Os to trigger actions or react to the status of a		
I/O Tab Control	Use I/O Tab Cont programmers, or programs. Operational Mode Reduced Mode Safeguard Reset 3-Position Switch Freedrive Enable	Use I/O Tab Control to specify whether an output is controlled on the I/O tab (by either programmers, or both operators and programmers), or if it is controlled by the robot programs. Operational Mode Reduced Mode Safeguard Reset 3-Position Switch Freedrive Enabled Input		
Available				
Input	Command	Action		
Actions	Start	Starts or resumes the current program on a rising edge (only enabled in Remote Control)		
	Stop	Stops the current program on a rising edge		
	Pause	Pauses the current program on a rising edge		
	When the input is high, the robot goes into freedrive (similar to the freedrive button).The input is ignored if other conditions disallow freedrive.			
	WAF If the move the re to the	RNING robot is stopped while using the Start input action, the robot slowly es to the first waypoint of the program before executing that program. If obot is paused while using the Start input action, the robot slowly moves e position from where it was paused before resuming that program.		

Available Output Actions

Action	Output state	Program state
Low when not running	Low	Stopped or paused
High when not running	High	Stopped or paused
High when running, low when stopped	Low High	Running, Stopped or paused
Low on unscheduled stop	Low	Program terminated unscheduled
Low on unscheduled stop, otherwise High	Low High	Program terminated unscheduled Running, stopped or paused
Continuous Pulse	Alternates between high and low	Running (pause or stop the program to maintain the pulse state)

Program Termination Cause

An unscheduled program termination can occur for any of the reasons listed below:

- Robot stop
- Fault
- Violation
- Runtime exception

# 8.6.2. Using I/O for Mode Selection

Description	The robot can be configured to switch between operational modes without using the Teach Pendant. This means using the TP is prohibited when switching from Automatic mode to Manual mode and from Manual mode to Automatic mode. Switching modes without the use of the Teach Pendant requires safety I/O configuration and a secondary device as a mode selector.
Mode selector	The mode selector can be a key switch with a redundant electrical layout or with signals from a dedicated safety PLC.
To use the mode selector	<ul><li>Using the mode selector, such as a key switch, prevents the TP from being used to switch between the modes.</li><li>1. Connect your mode selector to the inputs as shown in the image below.</li><li>2. Verify the mode selector is correctly connected and configured.</li></ul>
	Key Switch



To configureConfiguring the safey inputs for the secondary device connection requires unlocking the<br/>safety I/O screen.safety inputs1In the Navigation menu, tan Application

- 1. In the Navigation menu, tap **Application**.
- 2. Select Safety.
- 3. At the bottom of the screen, tap **Unlock**.

When prompted, input your password to unlock the Safety screen.

If you have not previously defined a password, use the default password: ursafe.

- 4. Under Safety I/O select Inputs.
- 5. Select one of the input signals by tapping one of the Input dropdown options.
- 6. In the dropdown list, select Operational Mode.
- 7. Tap **Apply** and allow the robot restart.
- 8. Tap Confirm Safety Configuration.

You can now only use the secondary device to select and/or switch between operational modes.

Once the input is assigned to the secondary device, switching modes via the TP is disabled. If an attempt is made to use the TP to switch modes, a message appears confirming the TP cannot be used to change the operational mode.

# 8.6.3. Three Position Enabling Device

**Description** The robot arm is equipped with an enabling device in the form of the 3PE Teach Pendant. The Control Box supports the following enabling device configurations:

- 3PE Teach Pendant
- External Three-Position Enabling device
- External Three-Position device and 3PE Teach Pendant

The illustration below shows how to connect a Three-Position Enabling device.



Note: The two input channels for the Three-Position Enabling Device input have a disagreement tolerance of 1 second.



### NOTICE

The UR robot safety system does not support multiple external Three-Position Enabling Devices.

### Operational Mode Switch

Using a Three-Position Enabling device requires the use of an Operational Mode switch.

The illustration below shows an Operational Mode switch.



# 8.6.4. Safety I/O Signals

	provid	des a Calegory 3 Pl			
			🗁 Default	P	
		← Safety		00 00 00 00	
	Application	✓ Robot Limits	Inputs	< <sup>4</sup> → → Move	
	Program	Robot Limits	Function Signal		
	G 3D	✓ Joint Limits Joint Speeds	Function CI 0 Safeguard Reset CI 1	Program structure	
	Q Operator	Joint Positions	Granction CI 2 Unassigned CI 3	{×} Global Variabiles	
		Inputs	Function CI 4 Unassigned CI 5		
			Outputs	Function Cl 6	
		Planes     Planes	Unassigned CI 7		
		✓ Hardware			
		Hardware			
		A Lock Apply			
		Robot State Off	000	- Speed +	

Figure 1.3: PolyScope X screen displaying the Input signals.

=			B	Program name Default		Z
	$\leftarrow$	Safety				CC CC CC CC
Application	~	Robot Limits	Outputs			÷ ئ⇒ Move
Program		Robot Limits	Function	Signal	OSSD	
3D	ř	Joint Limits Joint Speeds	Function Unassigned	CO 0 CO 1		Program structure
Q Operator	~	Joint Positions Safety I/O	Function Unassigned	CO 2 CO 3		{x} Global Variables
		Inputs	Function Unassigned	CO 4 CO 5		
	~	Planes	Function V Unassigned	CO 6 CO 7		
		Planes				
	ľ	Hardware Hardware				
		Lock Apply				
	Robot Stat Off	e	C		- Speed	+

Emergency Stop Button	Performs a Stop Category 1 (IEC 60204-1) informing other machines using the System Stop output if that output is defined. A stop is initiated in anything connected to the output.
Robot	Performs a Stop Category 1 (IEC 60204-1) via Control Box input,
Emergency Stop	informing other machines using the System Emergency Stop Output if that output is defined.
External Emergency Stop	Performs a Stop Category 1 (IEC 60204-1) on robot only.
Reduced	All safety limits can be applied while the robot is using a <b>Normal</b> configuration, or a <b>Reduced</b> configuration. When configured, a low signal sent to the inputs causes the safety system to transition to the reduced configuration. The robot arm decelerates to satisfy the reduced parameters. The safety system guarantees the robot is within reduced limits less than 0.5s after the input is triggered. If the robot arm continues to violate any of the reduced limits, a Stop Category 0 is triggered. Trigger planes can also cause a transition to the reduced configuration. The safety system transitions to the normal configuration in the same way.

## Input The inputs are described in the tables below:

## Signals

Operational Mode	When an external mode selection is used it switches between <b>Automatic Mode</b> and <b>Manual Mode</b> . The robot is in Automatic mode when input is <i>low</i> and Manual mode when the input is <i>high</i> .
Safeguard Reset	Returns from the Safeguard Stop state, when a rising edge on the Safeguard Reset input occurs. When a Safeguard Stop occurs, this input ensures that the Safeguard Stop state continues until a reset is triggered.
Safeguard	A stop triggered by a safeguard input. Performs a Stop Category 2 (IEC 60204-1) in all modes, when triggered by a Safeguard.
Automatic Mode Safeguard Stop	Performs a Stop Category 2 (IEC 60204-1) in Automatic mode ONLY. Automatic Mode Safeguard Stop can only be selected when a Three- Position Enabling Device is configured and installed.
Automatic Mode Safeguard Reset	Returns from the Automatic Mode Safeguard Stop state when a rising edge on the Automatic Mode Safeguard Reset input occurs.
Freedrive on robot	You can configure the Freedrive input to enable and use Freedrive without pressing the Freedrive button on a standard TP, or without having to press-and-hold any of the buttons on the 3PE TP in the light-press position.



### Signals



### WARNING

When the default Safeguard Reset is disabled, an automatic reset happens when the safeguard no longer triggers a stop.

This can happen if a person passes though the field of the safeguard. If a person is not detected by the safeguard and the person is exposed to hazards, automatic reset is forbidden by standards.

• Use the external reset to ensure resetting only when a person is not exposed to hazards.



### WARNING

When Automatic Mode Safeguard stop is enabled, a safeguard Stop is not triggered in Manual Mode.

- Output All safety outputs go low in the event of a safety system violation or fault. This means the Signals System Stop output initiates a stop even when an E-stop is not triggered.
  - You can use the following Safety functions output signals. All signals return to low when the state which triggered the high signal has ended:

<sup>1</sup> System Stop	Signal is <i>Low</i> when the safety system has been triggered into a stopped state including by the Robot Emergency Stop input or the Emergency Stop Button. To avoid deadlocks, if the Emergency Stopped state is triggered by the System Stop input, low signal will not be given.
Robot Moving	Signal is <i>Low</i> if the robot is moving, otherwise high.
Robot Not Stopping	Signal is <i>High</i> when the robot is stopped or in the process of stopping due to an emergency stop or safeguard stop. Otherwise it will be logic low.
Reduced	Signal is <i>Low</i> when reduced parameters are active or if the safety input is configured with a reduced input and the signal is currently low. Otherwise the signal is high.
Not Reduced	This is the inverse of Reduced, defined above.
3-Position Enabling Device	In Manual Mode, an external 3-Position Enabling Device must be pressed and held in the center-on position to move the robot. If you are using a built-in 3-Position Enabling Device, the button must be pressed and held in the mid position to move the robot.
Safe Home	Signal is <i>High</i> if the robot arm is stopped and is located in the configured Safe Home Position. Otherwise, the signal is <i>Low</i> . This is often used when UR robots are integrated with mobile robots.

## NOTICE

Any external machinery receiving its Emergency Stop state from the robot through the System Stop output must comply with ISO 13850. This is particularly necessary in setups where the Robot Emergency Stop input is connected to an external Emergency Stop device. In such cases, the System Stop output becomes high when the external Emergency Stop device is released. This implies that the emergency stop state at the external machinery will be reset with no manual action needed from the robot's operator. Hence, to comply with safety standards, the external machinery must require manual action in order to resume.

<sup>&</sup>lt;sup>1</sup>System Stop was previously known as "System Emergency Stop" for Universal Robots robots. PolyScope can display "System Emergency Stop".

# 8.7. General Purpose Digital I/O

Description	The Startup screen contains settings for automatically loading and starting a default program, and for auto-initializing the Robot arm during power up.
General purpose digital I/O	This section describes the general purpose 24V I/O (Gray terminals) and the configurable I/O (Yellow terminals with black text) when not configured as safety I/O.
	The general purpose I/O can be used to drive equipment like pneumatic relays directly or for communication with other PLC systems. All Digital Outputs can be disabled automatically when program execution is stopped. In this mode, the output is always low when a program is not running. Examples are shown in the following subsections.

These examples use regular Digital Outputs but any configurable outputs could also have be used if they are not configured to perform a safety function.





In this example a load is controlled from a Digital In this example a simple button is Outputs when connected.

connected to a Digital Input.

Communication with other machines or **PLCs** 

You can use the digital I/O to communicate with other equipment if a common GND (0V) is established and if the machine uses PNP technology, see below.



# 8.7.1. Remote ON/OFF control

**Description** Use remote **ON/OFF** control to turn the Control Box on and off without using the Teach Pendant. It is typically used:

- When the Teach Pendant is inaccessible.
- When a PLC system must have full control.
- When several robots must be turned on or off at the same time.

Remote The remote ON/OFF control provides a auxiliary 12V supply, kept active when the Control Box is turned off. The ON input is intended only for short time activation and works in the same way as the POWER button. The OFF input can be held down as desired. Use a software feature to load and start programs automatically.

The electrical specifications are shown below.

Terminals	Parameter	Min	Тур	Max	Unit
[12V - GND]	Voltage	10	12	13	V
[12V - GND]	Current	-	-	100	mA
[ON / OFF]	Inactive voltage	0	-	0.5	V
[ON / OFF]	Active voltage	5	-	12	V
[ON / OFF]	Input current	-	1	-	mA
[ON]	Activation time	200	-	600	ms



## CAUTION

Maintaining a press and hold on the power button switches the Control Box OFF without saving.

- Do not press and hold the ON input or the POWER button without saving.
- Use the **OFF** input for remote off control to allow the Control Box to save open files and shut down correctly.

# 8.8. General Purpose Analog I/O

Description

The analog I/O interface is the green terminal. It is used to set or measure voltage (0-10V) or current (4-20mA) to and from other equipment.

The following directions is recommended to achieve the highest accuracy.

- Use the AG terminal closest to the I/O. The pair share a common mode filter.
- Use the same GND (0V) for equipment and Control Box. The analog I/O is not galvanically isolated from the Control Box.
- Use a shielded cable or twisted pairs. Connect the shield to the GND terminal at the terminal called Power.
- Use equipment that works in current mode. Current signals are less sensitive to ٠ interferences.

# Electrical

Specifications

In the GUI you can select input modes. The electrical specifications are shown below.

Terminals	Parameter	Min	Тур	Max	Unit
Analog Input in current mode					
[AIX - AG]	Current	4	-	20	mA
[AIX - AG]	Resistance	-	20	-	ohm
[AIX - AG]	Resolution	-	12	-	bit
Analog Input in voltage mode					
[AIX - AG]	Voltage	0	-	10	V
[AIX - AG]	Resistance	-	10	-	Kohm
[AIX - AG]	Resolution	-	12	-	bit
Analog Output in current mode					
[AOx - AG]	Current	4	-	20	mA
[AOx - AG]	Voltage	0	-	24	V
[AOx - AG]	Resolution	-	12	-	bit
Analog Output in voltage mode					
[AOx - AG]	Voltage	0	-	10	V
[AOX - AG]	Current	-20	-	20	mA
[AOX - AG]	Resistance	-	1	-	ohm
[AOx - AG]	Resolution	-	12	-	bit



This example illustrates controlling a conveyor belt with an analog speed control input.

This example illustrates connecting an analog sensor.

# 9. End Effector Integration

Description

The end effector can also be referred to as the tool and the workpiece in this manual.

## NOTICE

UR provides documentation for the end effector to be integrated with the robot arm.

• Refer to the documentation specific to the end effector/tool/workpiece for mounting and connection.

# 9.1. Maximum Payload

#### Description

The rated robot arm payload depends on the center of gravity (CoG) offset of the payload, as shown below. The CoG offset is defined as the distance from the center of the tool flange to the center of gravity of the attached payload.

The robot arm can accommodate a long center of gravity offset, if the payload is placed below the tool flange. For example when computing the payload mass in a pick and place application, consider both the gripper and the workpiece.

The robot's capacity to accelerate can be reduced if the payload CoG exceeds the robot's reach and payload. You can verify the reach and payload of your robot in the Technical Specifications.



Payload capacity increase The robot arm can accommodate higher payloads and longer CoG offsets, if the payload is placed below the tool flange. You can increase the maximum payload capacity of the robot arm, under the following criteria:

- Movement with high payload is with tool oriented vertically downward, as is often the case in palletizing applications.
- The payload CoG is within the nominal horizontal reach of the robot.
- The CoG offset in the horizontal XY-plane does not exceed the expanded payload curve (long offsets in the Z-axis, exceeding the payload curve are not an issue).



Example of how to compute the horizontal center of gravity offset.

As illustrated above, the horizontal payload offset  $d_v$  should be within the payload curve.

Expanded payload is possible for any robot mounting orientation.

Increasing the maximum payload capacity can cause the robot to move at reduced speeds and lower acceleration. The higher load on the joints can limit some motions inside the working range of the robot. The robot software automatically ensures the mechanical limits of the robot are not exceeded.



## NOTICE

Using the expanded payload range does not void your robot warranty for this robot.

PayloadYou can configure high inertia payloads, if the payload is set correctly.inertiaThe controller software automatically adjusts accelerations when the following parameters are correctly configured:

- Payload mass
- Center of gravity
- Inertia

You can use the URSim to evaluate the accelerations and cycle times of the robot motions with a specific payload.

# 9.2. Securing Tool

**Description** The tool or workpiece is mounted to the tool output flange (ISO) at the tip of the robot.



Dimensions and hole pattern of the tool flange. All measurements are in millimeters.

**Tool flange** The tool output flange (ISO 9409-1) is where the tool is mounted at the tip of the robot. It is recommended to use a radially slotted hole for the positioning pin to avoid over-constraining, while keeping precise position.

### CAUTION

Very long M6 bolts can press against the bottom of the tool flange and short circuit the robot.

• Do not use bolts that extend beyond 8 mm to mount the tool.

### WARNING

Failure to tighten bolts properly cause injury due to loss of the adapter flange and/or end effector.

- Ensure the tool is properly and securely bolted in place.
- Ensure the tool is constructed such that it cannot create a hazardous situation by dropping a part unexpectedly.

# 9.3. Tool I/O

#### Tool Connector

The tool connector illustrated below provides power and control signals for the grippers and sensors used on a specific robot tool. The tool connector has eight holes and is located next to the tool flange on Wrist 3.

The eight wires inside the connector have different functions, as listed below:

	Pin #	Signal	Description
_	1	AI3 / RS485-	Analog in 3 or RS485-
6 7	2	Al2 / RS485+	Analog in 2 or RS485+
	3	TO0/PWR	Digital Outputs 0 or 0V/12V/24V
50 08 0	4	TO1/GND	Digital Outputs 1 or Ground
072	5	POWER	0V/12V/24V
	6	TIO	Digital Inputs 0
3	7	TI1	Digital Inputs 1
	8	GND	Ground



### NOTICE

The Tool Connector must be manually tightened up to a maximum of 0.4 Nm.

### Tool I/O Accessories

The tool I/O for all Universal Robots robots can require an accessory element to facilitate connection with tools. You can use the Tool Cable Adapter.

Tool CableThe Tool Cable Adapter is the electronic accessory that allows compatibility between tool I/OAdapterand tools.





The eight wires inside the Tool Cable Adapter have different functions, as listed below:



	Pin #	Signal	Description
	1	Al2 / RS485+	Analog in 2 or RS485+
	2	AI3 / RS485-	Analog in 3 or RS485-
2	3	TI1	Digital Inputs 1
	4	TI0	Digital Inputs 0
1	5 POWER		0V/12V/24V
	6	TO1/GND	Digital Outputs 1 or Ground
	7	TO0/PWR	Digital Outputs 0 or 0V/12V/24V
	8	GND	Ground



### GROUND

The tool flange is connected to GND (Ground).

# 9.3.1. Tool I/O Installation Specifications

#### Description

The electrical specifications are shown below. Access Tool I/O in the Installation Tab to set the internal power supply to 0V, 12V or 24V.

Parameter	Min	Тур	Max	Unit
Supply voltage in 24V mode	23.5	24	24.8	V
Supply voltage in 12V mode	11.5	12	12.5	V
Supply current (single pin)*	-	1000	2000**	mA
Supply current (dual pin)*	-	2000	2000**	mA
Supply capacitive load	-	-	8000***	uF

\* It is highly recommended to use a protective diode for inductive loads.

\*\* Peak for max 1 second, duty cycle max: 10%. Average current over 10 seconds must not exceed typical current.

\*\*\* When tool power is enabled, a 400 ms soft start time begins allowing a capacitive load of 8000 uF to be connected to the tool power supply at start-up. Hot-plugging the capacitive load is not allowed.

# 9.3.2. Tool Power Supply



# 9.3.3. Tool Digital Inputs

**Description** The Startup screen contains settings for automatically loading and starting a default program, and for auto-initializing the Robot arm during power up.

----

# TableThe Digital Inputs are implemented as PNP with weak pull-down resistors. This means that a<br/>floating input always reads as low. The electrical specifications are shown below.

Parameter	Min	Туре	Max	Unit
Input voltage	-0.5	-	26	V
Logical low voltage	-	-	2.0	V
Logical high voltage	5.5	-	-	V
Input resistance	-	47k	-	Ω

TI0

Using the Tool Digital	This example illustrates connecting a simple button.				
Inputs	POWER	_			
		· · · · · · · · · · · · · · · · · · ·			

User Manual

# 9.3.4. Tool Digital Outputs

### Description

ion Digital Outputs support three different modes:

Mode	Active	Inactive
Sinking (NPN)	Low	Open
Sourcing (PNP)	High	Open
Push / Pull	High	Low

Access Tool I/O in the Installation Tab to configure the output mode of each pin. The electrical specifications are shown below:

Parameter	Min	Тур	Max	Unit
Voltage when open	-0.5	-	26	V
Voltage when sinking 1A	-	0.08	0.09	V
Current when sourcing/sinking	0	600	1000	mA
Current through GND	0	1000	3000*	mA

## NOTICE

Once the robot makes an Emergency Stop, the Digital Outputs (DO0 and DO1) are deactivated (High Z).



## CAUTION

The Digital Outputs in the tool are not current-limited. Overriding the specified data can cause permanent damage.

Using Tool Digital Outputs

Tool This example illustrates turning on a load using the internal 12V or 24V power supply. The output voltage at the I/O tab must be define. There is voltage between the POWER connection and the shield/ground, even when the load is turned off.



It is recommended to use a protective diode for inductive loads, as shown below.



# 9.3.5. Tool Analogue Inputs

#### Description

Tool Analogue Input are non-differential and can be set to either voltage (0-10V) or current (4-20mA) on the I/O tab. The electrical specifications are shown below.

Parameter	Min	Туре	Max	Unit
Input voltage in voltage mode	-0.5	-	26	V
Input resistance @ range 0V to 10V	-	10.7	-	kΩ
Resolution	-	12	-	bit
Input voltage in current mode	-0.5	-	5.0	V
Input current in current mode	-2.5	-	25	mA
Input resistance @ range 4mA to 20mA	-	182	188	Ω
Resolution	-	12	-	bit

Two examples of using Analog Input are shown in the following subsections.

Caution



### CAUTION

Analog Inputs are not protected against over voltage in current mode. Exceeding the limit in the electrical specification can cause permanent damage to the input.

Using Tool
Analog Inputs,
Non-
differential

This example shows an analog sensor connection with a non-differential output. The sensor output can be either current or voltage, as long as the input mode of that Analog Input is set to the same on the I/O tab.

Note: You can check that a sensor with voltage output can drive the internal resistance of the tool, or the measurement might be invalid.



Using Tool This example shows an analog sensor connection with a differential output. Connecting the negative output part to GND (0V), works in the same way as a non-differential sensor.



# 9.4. Set Payload

# 9.4.1. Safely Setting the Active Payload

Verify installation	e using PolyScope X, verify that the Robot Arm and Control Box are correctly led.		
	1. On the Teach Pendant, press the emergency stop button.		
	2. On the screen, tap <b>OK</b> when the Robot Emergency Stop box appears.		
	<ol><li>On the Teach Pendant, press the power button and allow the system to start and load PolyScope X.</li></ol>		
	4. Tap the on-screen <b>Power</b> button at the bottom left of the screen.		
	5. Hold and twist the emergency stop button to unlock.		
	6. On the screen's footer, verify the Robot State is Off.		
	7. Step outside the reach (workspace) of the robot arm.		
	8. Tap the on-screen <b>Power</b> button.		
	9. In the Initialize box, tap <b>Power On</b> , and the robot state is changed to <b>Locked</b> .		
	10. In the Active Payload, verify the payload mass.		
	You can also verify the mounting position is correct, in the 3D view.		
	11. Tap the Active Payload field, and an Edit field appears in the main screen.		
	12. Enter your active payload and Confirm.		
	Configuration Edit X Active Payload S		



13. Tap **Unlock** for the robot arm to release its brake system.

# 10. Configuration

# 10.1. Settings

Description	The settings in PolyScope X can be access via the hamburger menu in the top left corner. You can access the following sections:			
	General			
	Password			
	Connection			
	Security			
General Settings	In the general settings, you can change the preferred language, units of measurements, etc. You also update the software from the general settings.			
Password Settings	In the password settings, you can find the default passwords, and how to change them to the preferred and secure passwords.			
Connection Settings	In the connection settings, you can set network settings such as IP address, DNS server, etc. Settings related to UR Connect is also found here.			
Security Settings	The security settings related to SSH, admin password permissions and enabling/disabling of various services in the software.			

## 10.1.1. Password

Description

In the password settings in PolyScope X, you can find three different types of password.

- Operational Mode
- Safety
- Admin

It is possible to set the same password in all three instances, but it is also possible to set three different password to separate access and options.

## Password - Admin

Description

All options under Security are protected by an Admin password. The Admin password protected screens are locked by a transparent overlay rendering the settings unavailable. Accessing the Security allows you to configure the settings in the following:

- Secure Shell
- Permissions
- Services

The settings can only the modified by designated administrator/s. Unlocking any one of the options under Security, also unlocks the other options until you exit the Settings menu.

Default Password



#### NOTICE

The default password for the admin password is: easybot

If you forget your admin password, it cannot be replaced or recovered. You will have to reinstall the software. To set theBefore you can use the Admin password to unlock protected screens, you have to changeAdminthe default password.

password

## 1. Access the Hamburger menu and select Settings

- 2. Under Password, tap Admin.
- 3. Change the current Admin password to a new one.
  - If this is the first time, change the default Admin password from "easybot" to a new password. The new password must be at least 8 characters long.
- 4. Use the new password to unlock the Settings menu and access the options under Security.

@ s	Settings		×
~	General	Admin	
	System Update	Change password Set password used when changing system settings	
~	Password Operational Mode Safety	New Password	
	Admin	Change password	
×	Connection	This password connet be recovered if you forget or mightee it	
	Network	You will have to reinstall the software.	
	UR Connect		
	Security		
	Permissions		
	Services		
			Close



1. On the Settings menu locate and tap the Lock and Close button.

## **Password - Operational Mode**

Default Password



### NOTICE

The default password for operational mode: operator

If you forget your password, it cannot be replaced or recovered. You will have to reinstall the software.

You must use the default password, when you change the password for the first time.
Change Operational Mode Password This is how you change the password for operational mode in the PolyScope X settings.

- 1. Click the hamburger menu in the top left corner.
- 2. Click Settings.
- 3. Click Operational Mode in the Password section.
- 4. Add the default password, if it is the first time.
- 5. Add your preferred password, at least 8 characters.

Ø	Settings		×
~	General	Operational Mode	
	System	Change password	
	Update	Old Password	
~	Password	New Password	
	Operational Mode		
	Safety	Repeat Password	
	Admin	Change password	
×	Connection		
	Network	ev.	
	UR Connect		
~	Security		
	Secure shell		
	Permissions		
	Services		
			Olass
			Close

### **Password - Safety**

Default Password



NOTICE

The default password for safety: ursafe

If you forget your password, it cannot be replaced or recovered. You will have to reinstall the software.

You have to use the default password, when you change the password for the first time.

Change Safety

Password

This is how you change the safety password in the PolyScope X settings.

- 1. Click the hamburger menu in the top left corner.
- 2. Click Settings.
- 3. Click Safety in the Password section.
- 4. Add the default password, if it is the first time.
- 5. Add your preferred password, at least 8 characters.

Ø	Settings		×
~	General	Safety	
	System	Change password	
	Update	Set password to change safety settings Old Password	
$\sim$	Password		
	Operational	al Mode	
	Safety	Repeat Password	
	Admin	Change password	
$\sim$	Connectio	on	
	Network		
	UR Connect	ct	
$\sim$	Security		
	Secure she	ell	
	Permission	ns	
	Services		
			Close

### 10.1.2. Secure Shell (SSH) Access

Description	You can manage remote access to the robot using Secure shell (SSH). The Secure shell security settings screen allows administrators to enable or disable SSH access to the robot.		
To enable/disable SSH	<ol> <li>Access the Hamburger menu and select Settings.</li> <li>Under Security, tap Secure shell.</li> <li>Slide the Enable SSH Access to the on position.</li> </ol>		
	for SSH communication.		
SSH Authentication	Authentication can occur with a password and/or with a pre-shared, authorized key. Security keys can be added by tapping the <b>Add Key</b> button and selecting a security key file. Available keys are listed together. Use the trash icon to remove a selected key from the list.		

### 10.1.3. Permissions

Description	Access to the Networking, URCap Management and Updating PolyScope X screens is restricted by default, to prevent unauthorized changes to the system. You can change the permission settings to allow access to these screens. An Admin password is required to access Permissions.
To access Permissions	<ol> <li>Access the Hamburger menu and select Settings.</li> <li>Navigate to Security and tap Permissions.</li> </ol>
Additional system permissions	You can also lock a few important screens/functionalities with the Admin password. On the Permissions screen in Security section in the Settings menu, it is possible to specify which additional screens are to be protected by the Admin password and which screens are available to all users. The following screens/functionalities can optionally be locked: • Network settings • Update settings • URCaps section in the System Manager

To enable/disable	<ol> <li>Access Permission as previously described. The protected screens are listed under Permissions.</li> </ol>
system permissions	<ol> <li>For the desired screen, slide the On/Off toggle switch to the On position to enable it.</li> </ol>
	3. To disable the desired screen, slide the On/Off toggle switch to the Off position.
	The screen locks again once the toggle is in the Off position.
10.1.4. Serv	ices
Description	Services allow administrators to enable or disable remote access to the standard UR services running on the robot, such as Primary/Secondary Client interfaces, PROFINET, Ethernet/IP, ROS2, etc.
	Use the Service screen to restrict remote access to the robot by only allowing external access to the services on the robot which the specific robot application is actually using. All services are disabled by default to provide maximum security. The communication ports for each service are to right of the On/Off toggle button in the list of services.
Enabling ROS2	When the ROS2 service is enabled on this screen, you can specify the ROS Domain ID (values 0-9). After changing the Domain ID, the system restarts to apply the change.

## 10.2. Safety Related Functions and Interfaces

Universal Robots robots are equipped with a range of built-in safety functions as well as safety I/O, digital and analog control signals to or from the electrical interface, to connect to other machines and additional protective devices. Each safety function and I/O is constructed according to EN ISO13849-1 with Performance Level d (PLd) using a category 3 architecture.



### WARNING

The use of safety configuration parameters different from those determined as necessary for risk reduction, can result in hazards that are not reasonably eliminated, or risks that are not sufficiently reduced.

• Ensure tools and grippers are connected correctly to avoid hazards due to interruption of power.



### WARNING: ELECTRICITY

Programmer and/or wiring errors can cause the voltage to change from 12V to 24V leading to fire damage to equipment.

• Verify the use of 12V and proceed with caution.



### NOTICE

- The use and configuration of safety functions and interfaces must follow the risk assessment procedures for each robot application.
- The stopping time should be taken into account as part of the application risk assessment
- If the robot detects a fault or violation in the safety system (e.g. if one of the wires in the Emergency Stop circuit is cut or a safety limit is exceeded), then a Stop Category 0 is initiated.

### NOTICE

The end effector is not protected by the UR safety system. The functioning of the end effector and/or connection cable is not monitored

### 10.2.1. Configurable Safety Functions

Universal Robots robot safety functions, as listed in the table below, are in the robot but are meant to control the robot system i.e. the robot with its attached tool/end effector. The robot safety functions are used to reduce robot system risks determined by the risk assessment. Positions and speeds are relative to the base of the robot.

Safety Function	Description
Joint Position Limit	Sets upper and lower limits for the allowed joint positions.
Joint Speed Limit	Sets an upper limit for joint speed.
Safety Planes	Defines planes, in space, that limit robot position. Safety planes limit either the tool/end effector alone or both the tool/end effector and the elbow.
Tool Orientation	Defines allowable orientation limits for the tool.
Speed Limit	Limits maximum robot speed. The speed is limited at the elbow, at the tool/end effector flange, and at the center of the user-defined tool/end effector positions.
Force Limit	Limits maximum force exerted by the robot tool/end effector and elbow in clamping situations. The force is limited at the tool/end effector, elbow flange and center of the user-defined tool/end effector positions.
Momentum Limit	Limits maximum momentum of the robot.
Power Limit	Limits mechanical work performed by the robot.
Stopping Time Limit	Limits maximum time the robot uses for stopping after a protective stop is initiated.
Stopping Distance Limit	Limits maximum distance travelled by the robot after a protective stop is initiated.

### 10.2.2. Safety Function

When performing the application risk assessment, it is necessary to take into account the motion of the robot after a stop has been initiated. In order to ease this process, the safety functions *Stopping Time Limit* and *Stopping Distance Limit* can be used.

These safety functions dynamically reduces the speed of the robot motion such that it can always be stopped within the limits. The joint position limits, the safety planes and the tool/end effector orientation limits take the expected stopping distance travel into account i.e. the robot motion will slow down before the limit is reached.

## 10.3. Safety Configuration

NOTICE

Safety Settings are password protected.

- 1. In the PolyScope X left header, tap the Application icon.
- 2. On the Workcell screen tap the Safety icon.
- 3. Observe that the Robot Limits screen displays, but settings are inaccessible.
- 4. Enter the safety password and tap UNLOCK to make settings accessible. Note: Once Safety settings are unlocked, all settings are now active.
- 5. Tap LOCK or navigate away from the Safety menu to lock all Safety item settings again.

## 10.4. Setting a Safety Password

- 1. In your PolyScope X header left corner, tap the Hamburger menu and then tap Settings.
- 2. On the left of the screen, in the blue menu, tap Safety Password.
- 3. For Old Password, type the current Safety password.
- 4. For New Password, type a password.
- 5. For Repeat Password, type the same password and tap Change Password.
- 6. In the top right of the menu, press CLOSE to return to previous screen.

## 10.5. Safety Menu Settings

The safety system limits are defined in the Safety Configuration. The safety system receives values from the input fields and detects any violation if any the values are exceeded. The robot controller prevents violations by making a robot stop or by reducing the speed.

### 10.5.1. Robot Limits

Application ←	Safety	Robot Inputs Outputs Planes Limits	
	Limit	Normal	Reduced
Program	Power	Power 300 W	Power 200 W
	Momentum	Momentum 25 kg·m/s	Momentum 10 kg·m/s
30	Stopping Time	Stopping Time 0.4 s	Stopping Time 0.3 s
Q Operator	Stopping Distance	Stopping Distance	Stopping Distance 0.3 m
	Tool Speed	Tool Speed 1.5 m/s	Tool Speed 0.75 m/s
	Tool Force	Tool Force 150 N	Tool Force 120 N
	Elbow Speed	Elbow Speed 1.5 m/s	Elbow Speed 0.75 m/s
	Elbow Force	Elbow Force 150 N	Elbow Force 120 N
		🖞 Unlock 🔒 Lock	Apply

Limit	Description	
Power	limits maximum mechanical work produced by the robot in the environment. This limit considers the payload a part of the robot and not of the environment.	
Momentum	limits maximum robot momentum.	
Stopping Time	limits maximum time it takes the robot to stop e.g. when an emergency stop is activated	
Stopping Distance	limits maximum distance the robot tool or elbow can travel while stopping.	
Tool Speed	limits maximum robot tool speed.	
Tool Force	limits the maximum force exerted by the robot tool in clamping situations	
Elbow Speed	limits maximum robot elbow speed	
Elbow Force	limits maximum force that the elbow exerts on the environment	

Safety Mode



### NOTICE

Restricting stopping time and distance affect overall robot speed. For example, if stopping time is set to 300 ms, the maximum robot speed is limited allowing the robot to stop within 300 ms.



### NOTICE

The tool speed and force are limited at the tool flange and the center of the two user-defined tool positions

Under normal conditions, i.e. when no Robot stop is in effect, the safety system operates in a Safety Mode associated with a set of safety limits 1:

Safety mode	Effect
Normal	This configuration is active by default.
Reduced	This configuration activates when the Tool Center Point (TCP) is positioned beyond a Trigger Reduced mode plane, or when triggered using a configurable input.

<sup>&</sup>lt;sup>1</sup>Robot stop was previously known as "Protective stop" for Universal Robots.

### 10.5.2. Safety Planes

#### Description

Safety planes restrict robot workspace, the tool and the elbow.



### WARNING

Defining safety planes only limits the defined Tool spheres and elbow, not the overall limit for the robot arm.

Defining safety planes does not guarantee that other parts of the robot arm will obey this type of restriction.



Figure 1.4: PolyScope X screen displaying safety planes.

IR **UNIVERSAL ROBOTS** 

Configuring a You can configure safety planes with the properties listed below: Safety Plane Name This is the name used to identify the safety plane.

- Offset from base This is the height of the plane from the base, measured in the -Y direction.
- Tilt This is the tilt of the plane, measured from the power cord.
- Rotation This is the rotation of the plane, measured clockwise. •

You can configure each plane with the restrictions listed below:

- Normal When the safety system is in Normal mode, a normal plane is active and it acts as a strict limit on the position.
- Reduced When the safety system is in Reduced mode, a reduced mode plane is active and it acts as a strict limit on the position.
- Both When the safety system is either in Normal or Reduced mode, a normal and reduced mode plane is active and acts as a strict limit on the position.
- ٠ Trigger Reduced Mode The safety plane causes the safety system to switch to Reduced mode if the robot Tool or Elbow is positioned beyond it.

Elbow Joint You can prevent the robot elbow joint from passing through any of your defined planes. Restriction

Disable Restrict Elbow for elbow to pass through planes.

## 11. Cybersecurity Threat Assessment

Description

This section provides information to help you strengthen the robot against potential cybersecurity threats. It outlines requirements for addressing cybersecurity threats and provides security hardening guidelines.

## 11.1. General Cybersecurity

#### Description

Connecting a Universal Robots robot to a network can introduce cybersecurity risks. These risks can be mitigated by using qualified personnel and implementing specific measures for protecting the robot's cybersecurity.

Implementing cybersecurity measures requires conducting a cybersecurity threat assessment.

The purpose is to:

- Identify threats
- · Define trust zones and conduits
- · Specify the requirements of each component in the application



#### WARNING

Failure to conduct a cybersecurity risk assessment can place the robot at risk.

• The integrator or competent, qualified personnel shall conduct a cybersecurity risk assessment.



### NOTICE

Only competent, qualified personnel shall be responsible for determining the need for specific cybersecurity measures and for providing the required cybersecurity measures.

### 11.2. Cybersecurity Requirements

#### Description

Configuring your network and securing your robot requires you to implement the threat measures for cybersecurity. Follow all the requirements before you start configure your network, then verify the robot setup is secure.

#### Cybersecurity

- Operating personnel must have a thorough understanding of general cybersecurity principles and advanced technologies as used in the UR robot.
- Physical security measures must be implemented to allow only authorized personnel physical access to the robot.
- There must be adequate control of all access points. For example: locks on doors, badge systems, physical access control in general.



### WARNING

Connecting the robot to a network that is not properly secured, can introduce security and safety risks.

• Only connect your robot to a trusted and properly secured network.

Network	<ul> <li>Only trusted devices are to be connected to the local network.</li> </ul>				
configuration	<ul> <li>There must be no inbound connections from adjacent networks to the robot.</li> </ul>				
requirements	<ul> <li>Outgoing connections from the robot are to be restricted to allow the smallest relevant set of specific ports, protocols and addresses.</li> </ul>				
	<ul> <li>Only URCaps and magic scripts from trusted partners can be used, and only after verifying their authenticity and integrity</li> </ul>				
Robot setup	<ul> <li>Change the default password to a new, strong password.</li> </ul>				
security	<ul> <li>Disable the "Magic Files" when not actively used (PolyScope 5).</li> </ul>				
requirements	<ul> <li>Disable SSH access when not needed. Prefer key-based authentication over password-based authentication</li> </ul>				
	<ul> <li>Set the robot firewall to the most restrictive usable settings and disable all unused interfaces and services, close ports and restrict IP addresses</li> </ul>				

### 11.3. Cybersecurity Hardening Guidelines

Description

Although PolyScope includes many features for keeping the network connection secure, you can harden security by observing to following guidelines:

• Before connecting your robot to any network, always change the default password to a strong password.

i	<b>NOTICE</b> You cannot retrieve or reset a forgotten or lost password.
	Store all passwords securely.

- Use the built-in settings to restrict the network access to the robot as much as possible.
- Some communication interfaces have no method of authenticating and encrypting communication. This is a security risk. Consider appropriate mitigating measures, based on your cybersecurity threat assessment.
- SSH tunneling (Local port forwarding) must be used to access robot interfaces from other devices if the connection crosses the trust zone boundary.
- Remove sensitive data from the robot before it is decommissioned. Pay particular attention to the URCaps and data in the program folder.
  - To ensure secure removal of highly sensitive data, securely wipe or destroy the SD card.

## 12. Communication Networks

### Fieldbus

You can use the Fieldbus options to define and configure the family of industrial computer network protocols used for real-time distributed control accepted by PolyScope:

- Ethernet/IP
- PROFINET

## 12.1. Profinet

# **Description** The PROFINET network protocol enables or disables the connection of the robot to an industrial PROFINET IO-Controller. If the connection is enabled, you can select the action that occurs when a program loses PROFINET IO-Controller connection.

### Enable Profinet

This is how you enable to Profinet function in PolyScope X.

- 1. In the top right of the screen, tap the Hamburger menu and then tap Settings.
- 2. In the menu on the left, under Security, tap Services.
- 3. Tap the Profinet button to switch Profinet on.

≡			Program name Default program		P
Application	~	Ø Settings		×	00 00 00 00
	~	System	Services		<b>€</b> Move
Program	, i	Update	Please be advised to keep unused interfaces disabled t	to improve security	
		✓ Password	Primary Client interface	Ports: 30001, 30011	Program
3D	↓ ▼ ↓	Operational Mode	Secondary Client interface	Ports: 30002, 30012	structure
Q		Safety	Real-Time Client interface	Ports: 30003, 30013	{×} Global
Operator	~ 1	Admin	Real-Time Data Exchange (RTDE)	Ports: 30004	Valiaties
		Network	Interpreter Mode Socket	Ports: 30020	
	× 1	✓ Security	Modbus TCP	Ports: 502	
		Secure shell	Ethernet/IP	Ports: 2222, 40000, 44818	
		Permissions	Profinet	Ports: 34962, 34963, 34964, 53247, 49152, 40002	
		Services		Close	
(R)	Robot State Active			Θ	<sup>Speed</sup> 100 % +

Using Find the profinet functions in PolyScope X: Profinet

ronnet

In the PolyScope X left header.

- 1. Tap the Application icon.
- 2. Select Profinet from the left menu.

Select the relevant action from the list:

Ignore	PolyScope X ignores the loss of Profinet connection, and the program
	continues to run.
Pause	PolyScope X pauses the current program. The program resumes from where it
	stopped.
Stop	PolyScope X stops the current program.

≡			Program name Default program		P
88	←	Communication			CC CC
Application Program G 30 Q Operator	*    *    *    *	Robot Wired IO Tool IO Modbus + Add Source Profinet Profinet EtherNet/IP EtherNet/IP	Device Name : Robot action upon loss of Profinet input connection Robot action upon loss of Profinet input connection Register Module 2 Connection Regis		<ul> <li>More</li> <li>More</li> <li>Programme</li> <li>(A)</li> <li>Variables</li> </ul>
(k)	Robot State Active			E Speed 100 %	+

## 12.2. Ethernet/IP

Description

EtherNet/IP is a network protocol that enables the connection of the robot to an industrial EtherNet/IP scanner device. If the connection is enabled, you can select the action that occurs when a program loses EtherNet/IP scanner device connection.

Enable Ethernet/IP This is how you enable to Ethernet/IP function in PolyScope X.

- 1. In the top right of the screen, tap the Hamburger menu and then tap Settings.
- 2. In the menu on the left, under Security, tap Services.
- 3. Tap the Profinet button to switch Profinet on.

≡			Default program		R
Application	~	Settings		×	00 00 00 00
	~ 1	System	Services		<b>↔</b> Move
Program		Update	Please be advised to keep unused interfaces disabled	to improve security	
~	v T	✓ Password	Primary Client interface	Ports: 30001, 30011	Program
3D		Operational Mode	Secondary Client interface	Ports: 30002, 30012	structure
R	-	Safety	Real-Time Client Interface	Ports: 30003, 30013	{x} Global Variables
Operator	V F	Admin	Real-Time Data Exchange (RTDE)	Ports: 30004	
	F	Network	Interpreter Mode Socket	Ports: 30020	
	~ E	✓ Security	Modbus TCP	Ports: 502	
	E	Secure shell	Ethernet/IP	Ports: 2222, 40000, 44818	
		Permissions	Profinet	Ports: 34962, 34963, 34964, 53247, 49152, 40002	
		Services			
				Close	
(k)	Robot State <b>Active</b>				Speed 100 % +

Using Ethernet/IP	Find the Ethernet/IP functions in PolyScope X:
	In the PolyScope X left header.

- 1. Tap the Application icon.
- 2. Select the relevant action from the list.
- Ignore PolyScope X ignores the loss of EtherNet/IP connection, and the program continues to run.
- Pause PolyScope X pauses the current program. The program resumes from where it stopped.

Stop PolyScope X stops the current program.

≡		Program name Default program	Ţ
88	$\leftarrow$ Communication		cc cc
Application Program Q Q Program Q Q Prestor	<ul> <li>Robot</li> <li>Wired IO</li> <li>Tool IO</li> <li>Modbus</li> <li>Add Source</li> <li>Profinet</li> <li>Profinet</li> <li>EtherNet/IP</li> <li>EtherNet/IP</li> </ul>	Connected	Kove Program stoucter (x) Global Variables
	Robot State Active		= Speed +

In the upper right corner of this screen, you can see the Ethernet/IP status.

Connected	The robot is connected to the Ethernet/IP Scanner Device.
No Scanner	Ethernet/IP is running, but no device is connected to the robot via Ethernet/IP.
Disabled	Ethernet/IP is not enabled.

## 12.3. UR Connect

Connect You have to connect your PolyScope X software to the myUR Cloud service. PolyScope X to You need to find you PIN code in your myUR account. myUR Cloud

- 1. Go to Settings.
- 2. Go to UR Connect.
- 3. Hit the "Connect" button on the main UR Connect page.
- 4. Add you pin code from myUR.

≡			Default program			P
Application	Appli	💮 Settings		×		
		✓ General	UR Connect	Disconnected		<b>€</b> ‡⇒ Move
Program	Mou	System		Disconnected		Program structure
3D Q	Rotat	<ul> <li>Password</li> <li>Operational Mode</li> </ul>	PIN Code			{x} Global Variables
Operator		Safety Admin				
	Safe	V Connection				
	Safet limits	UR Connect Security				
		Secure shell		Close		
$\bigcirc$	Robot State Off				Speed 100 %	+

When you see the green icon in the right corner of the window, you are connected to the myUR Cloud.





## **Unsuccessful** If you see the "Incorrect PIN code", please review your PIN code from myUR. connect

**Diagnostics** If you experience any unexpected when the UR Connect is active, you can go to the Diagnostics.

- 1. Go to Settings.
- 2. Go to UR Connect.
- 3. Hit the kebab menu in the top right corner.
- 4. Select the "Diagnostics".

≡		E Program name Default program	R
Application Frogram 30 Qenstor	Appli Mou Rotat Safet Imits	<ul> <li>Settings</li> <li>General</li> <li>System</li> <li>Update</li> <li>Password</li> <li>Operational Mode</li> <li>Safery</li> <li>Admin</li> <li>Connection</li> <li>Network</li> <li>UR Connect</li> <li>Security</li> <li>Secure shell</li> </ul>	CC CC Move Program structure {x} Globalles
	Robot State Off	Close Cl	+ • • •
Application Program 30 Operator	Appli Mou Rotat	Settings     General   System   UR Connect   System   Update   Operational Mode   Safery   Admin   Connection   Network   UR Connect URCap not installed   Operational Mode   Security	Code       Image: Angle of the second se
	Robot State Off		+

**Export logs** It is possible to export the UR Connect logs from your PolyScope X software.

- 1. Go to Settings.
- 2. Go to UR Connect.
- 3. Hit the kebab menu in the top right corner.
- 4. Select the "Export Logs"
- 5. Select "Export to myUR" or "Export to USB".

≡			Program Default	name t program		P	<b>4</b> ∰ Move	9 Joints	tcp	O Smart Skills
88					Preview		Move			
Application	TCP Offset	Settings		UR Connect				×	Active TCP Tool_flange	~
Program	X: 0.0 mm	System		UR Connect Diagnostics			Discon	nected	- Ro	itate
3D 3D Operator	Y: 0.0 mm Z: 0.0 mm RX: 0.00 * RY: 0.00 * RZ: 0.00 * Payload	Update Passwo Operatic Safety	∱ Export Lo	ogs	Ē		×			
	0.000 kg Center of Gravity X: 0.0 mm Y: 0.0 mm Z: 0.0 mm	Admin Connec Network UR Connec		Cr) Export to myUR	Export to USB				+	
		✓ Security Secure shell		① Diagnostics completed		1		Close		
	Robot State Off			D						peed 00 % +

## 13. Risk Assessment

#### Description

The risk assessment is a requirement that shall be performed for the application. The application risk assessment is the responsibility of the integrator. The user can also be the integrator.

The robot is partly completed machinery, as such the safety of the robot application depends on the tool/end effector, obstacles and other machines. The party performing the integration must use ISO 12100 and ISO 10218-2 to conduct the risk assessment. Technical Specification ISO/TS 15066 can provide additional guidance for collaborative applications. The risk assessment shall consider all tasks throughout the lifetime of the robot application, including but not limited to:

- Teaching the robot during set-up and development of the robot application
- Troubleshooting and maintenance
- Normal operation of the robot application

A risk assessment must be conducted **before** the robot application is powered on for the first time. The risk assessment is an iterative process. After physically installing the robot, verify the connections, then complete the integration. A part of the risk assessment is to determine the safety configuration settings, as well as the need for additional emergency stops and/or other protective measures required for the specific robot application.

Safety configuration settings Identifying the correct safety configuration settings is a particularly important part of developing robot applications. Unauthorized access to the safety configuration must be prevented by enabling and setting password protection.



### WARNING

Failure to set password protection can result in injury or death due to purposeful or inadvertent changes to configuration settings.

- Always set password protection.
- Set up a program for managing passwords, so that access is only by persons who understand the effect of changes.

Some safety functions are purposely designed for collaborative robot applications. These are configurable through the safety configuration settings. They are used to address risks identified in the application risk assessment.

The following limit the robot and as such can affect the energy transfer to a person by the robot arm, end effector and workpiece.

- Force and power limiting: Used to reduce clamping forces and pressures exerted by the robot in the direction of movement in case of collisions between the robot and the operator.
- **Momentum limiting**: Used to reduce high transient energy and impact forces in case of collisions between robot and operator by reducing the speed of the robot.
- Speed limitation: Used to ensure the speed is less that the configured limit.

The following orientation settings are used to avoid movements and reduce exposure of sharp edges and protrusions to a person.

- Joint, elbow and tool/end effector position limiting: Used to reduce risks associated with certain body parts: Avoid movement towards head and neck.
- Tool/end effector orientation limiting: Used to reduce risks associated with certain areas and features of the tool/end effector and work-piece: Avoid sharp edges being pointed towards the operator, by turning the sharp edges inward towards the robot.

Stopping performance risks Some safety functions are purposely designed for any robot application. These features are configurable through the safety configuration settings. They are used to address risks associated with the stopping performance of the robot application.

The following limit the robot stopping time and stopping distance to ensure stopping will occur before reaching the configured limits. Both settings automatically affect the speed of the robot to ensure the limit is not exceeded.

- Stopping Time Limit: Used to limit the stopping time of the robot.
- Stopping Distance Limit: Used to limit the stopping distance of the robot.

If either of the above is used, there is no need for manually performed periodic stopping performance testing. The robot safety control does continuous monitoring.

If the robot is installed in a robot application where hazards cannot be reasonably eliminated or risks cannot be sufficiently reduced by use of the built-in safety-related functions (e.g. when using a hazardous tool/end effector, or hazardous process), then safeguarding is required.



### WARNING

Failure to conduct a application risk assessment can increase risks.

• Always conduct an application risk assessment for foreseeable risks and reasonably foreseeable misuse.

For collaborative applications, the risk assessment includes the foreseeable risks due to collisions and to reasonably foreseeable misuse.

The risk assessment shall address:

- Severity of harm
- Likelihood of occurrence
- Possibility to avoid the hazardous situation

PotentialUniversal Robots identifies the potential significant hazards listed below for considerationhazardsby the integrator. Other significant hazards can be associated with a specific robot<br/>application.

- Penetration of skin by sharp edges and sharp points on tool/end effector or tool/end effector connector.
- Penetration of skin by sharp edges and sharp points on nearby obstacles.
- Bruising due to contact.
- Sprain or bone fracture due to impact.
- Consequences due to loose bolts that hold the robot arm or tool/end effector.
- Items falling out of, or flying from the tool/end effector, e.g. due to a poor grip or power interruption.
- Mistaken understanding of what is controlled by multiple emergency stop buttons.
- Incorrect setting of the safety configuration parameters.
- Incorrect settings due to unauthorized changes to the safety configuration parameters.

## 13.1. Pinch Hazard

#### Description

You can avoid pinching hazards by removing obstacles in these areas, by placing the robot differently, or by using a combination of safety planes and joint limits to eliminate the hazards by preventing the robot moving into this area of its workspace.





Due to the physical properties of the robot arm, certain workspace areas require attention regarding pinching hazards. One area (left) is defined for radial motions when the wrist 1 joint is at least 1150 mm from the base of the robot. The other area (right) is within 400 mm of the base of the robot, when moving tangentially.

### 13.2. Stopping Time and Stopping Distance

Description

The graphical data provided for **Joint 0 (base)**, **Joint 1 (shoulder)** and **Joint 2 (elbow)** is valid for stopping distance and stopping time:

- Category 0
- Category 1
- Category 2

The **Joint 0** test was carried out using a horizontal movement, where the rotational axis was perpendicular to the ground. During the **Joint 1** and **Joint 2** tests, the robot followed a vertical trajectory, where the rotational axes were parallel to the ground, and the stop was done while the robot was moving downward.

The Y-axis is the distance from where the stop is initiated to the final position.



#### NOTICE

You can set user-defined safety rated maximum stopping times and distances. If user-defined settings are used, the program speed is dynamically adjusted to always comply with the selected limits.



Speed [%]

100

33



139



### Joint 1 (SHOULDER)

Stopping time in seconds for 33% of 17.5kg







UR15 PolyScope X

## 14. Emergency Events

### Description

Follow the instructions here to handle emergency situations, such as activating the emergency stop using the red push-button. This section also describes how to manually move the system without power.

## 14.1. Emergency Stop

### Description

The Emergency Stop or E-stop is the red push-button located on the Teach Pendant. Press the emergency stop push-button to stop all robot motion. Activating the emergency stop push-button causes a stop category one (IEC 60204-1). Emergency stops are not safeguards (ISO 12100).

Emergency stops are complementary protective measures that do not prevent injury. The risk assessment of the robot application determines if additional emergency stop pushbuttons are required. The emergency stop function and the actuating device must comply with ISO 13850.

After an emergency stop is actuated, the push-button latches in that setting. As such, each time an emergency stop is activated, it must be manually reset at the push-button that initiated the stop.

Before resetting the emergency stop push-button, you must visually identify and assess the reason the E-stop was first activated. Visual assessment of all the equipment in the application is required. Once the problem is solved, reset the emergency stop pushbutton.

To reset the emergency stop push-button

1. Hold the push-button and twist clockwise until the latching disengages.

You should feel when the latching is disengaged, indicating the push-button is reset.

- 2. Verify the situation and whether to reset the emergency stop.
- 3. After resetting the emergency stop, restore power to the robot and resume operation.

### 14.2. Movement Without Drive Power

**Description** In the event of an emergency, when powering the robot is either impossible or unwanted, you can use forced back-driving to move the robot arm.

Forced back-driving requires you to push, or pull, the robot arm hard to move the joint. Bigger robot arms can involve more than one person to move the joint.

Each joint brake has a friction clutch that enables movement during high forced torque. Forced back-driving requires high force and one or more people may be required to move the robot.

In clamping situations, two or more people are required to do the forced back-driving. In some situations, two or more people are required to disassemble the robot arm.

Personnel using the UR robot are to be trained to respond to emergency events. Supplemental information shall be provided, on integration.



#### WARNING

Risks due to an unsupported robot arm breaking or falling can cause injury or death.

- Do not disassemble the robot during an emergency event.
- Support the robot arm before removing power.



#### NOTICE

Moving the robot arm manually is intended for emergency and service purposes only. Unnecessary moving of the robot arm can lead to property damage.

- Do not move the joint more than 160 degrees, to ensure the robot can find its original physical position.
- Do not move any joint more than necessary.

Description

## 14.3. Disassembly of Arm

	<ul><li>WARNING</li><li>Unsupported joints can fall, or be dropped, resulting in injury.</li><li>Support joints while clamps are being removed.</li></ul>
i	NOTICE Failure to support the joint/s while clamps are removed can result in damage to equipment.
	<ul> <li>Prevent the joint/s from falling while removing the clamp/s by doing any of the following:</li> </ul>
	<ul> <li>Use something to support underneath the part that is coming off.</li> </ul>
	<ul> <li>Disassemble the joint while it is laying down.</li> </ul>
	Support with lifting equipment

Failure to test the old joint before replacing it, can lead to damage to property and/or equipment.

Always perform a joint verification test before replacing a joint. See the Joint Verification section in the Service Manual for more information.

To Disassembl e

- 1. Attach the ESD wristband from the spare part package or tool kit to an electrical grounded surface.
- Remove the black flat-ring.
   You can use a pair of pointy tweezers or a small flathead screwdriver.



3. Remove the screws and the clamp on one side.



4. Support the joint as you remove the second side of the clamp.


5. The joint is now loose and can be removed.



6. Gently unplug the connector from the PCB on joint.



7. The joint has now been dismounted.

### 14.4. Operational Mode

Description

You access and activate different modes using Teach Pendant or the Dashboard Server. If an external mode selector is integrated, it control the modes - not PolyScope or the Dashboard Server.

Automatic Mode When this mode is activated the robot can only execute a program of pre-defined tasks. You cannot modify or save programs and installations.

**Manual Mode** When this mode is activated you can program the robot. You can modify and save programs and installations. The speeds used in Manual Mode must be limited to prevent injury. When the robot is operating in Manual Mode, a person could be positioned within reach of the robot. The speed must be limited to the value that is appropriate for the application risk assessment.



#### WARNING

Injury can occur if the speed used, while the robot is operating in Manual Mode, is too high.

**Recovery Mode** This mode activates when a safety limit from the active limit set is violated, the robot arm performs a Stop Category 0. If an active safety limit, such as a joint position limit or a safety boundary, is violated already when the robot arm is powered on, it starts up in Recovery mode. This makes it possible to move the robot arm back within the safety limits. In Recovery mode, the movement of the robot arm is restricted by a fixed limit that you cannot customize.

**High Speed Manual Mode** When this mode is enabled, you can temporarily exceed the default speed limit of the tool and the elbow.

The robot performs a Safeguard Stop in Manual mode, if a Three-Position Enabling Device is configured, and either released (not pressed) or it is fully compressed.

Switching between Automatic mode to Manual mode requires the Three-Position Enabling Device to be fully released and pressed again to allow the robot to move. When using High Speed Manual Mode, use safety joint limits or safety planes to restrict the robot's moving space.



#### NOTICE

After five minutes of inactivity the speed limit resets to the default.

#### To enable High Speed Manual

- 1. Tap Application and select Safety.
- 2. Access the Three Position page.
- 3. On the page, slide the button to enable Manual High Speed Mode.

#### Mode switching

Operational mode	Manual	Automatic
Move robot with +/- on Move Tab	x	
Freedrive	х	
Execute Programs	Reduced speed*	х
Edit & save program	x	

\*If a Three-Position Enabling device is configured, the robot operates at Manual Reduced Speed unless High Speed Manual Mode is enabled.



#### WARNING

- Any suspended safeguards must be returned to full functionality before selecting Automatic Mode.
- Wherever possible, Manual Mode shall only be used with all persons located outside the safeguarded space.
- If an external mode selector is used, it must be placed outside the safeguarded space.
- No-one is to enter, or be within, the safeguarded space in Automatic Mode, unless safeguarding is used or the collaborative application is validated for power and force limiting (PFL).

#### Three-Position Enabling Device

When a Three-Position Enabling Device is used and the robot is in Manual Mode, movement requires pressing the Three-Position Enabling Device to the center-on position. The Three-Position Enabling Device has no effect in Automatic Mode.



 Some UR robot sizes might not be equipped with a Three-Position Enabling Device. If the risk assessment requires the enabling device, a 3PE Teach Pendant must be used.

A 3PE Teach Pendant (3PE TP) is recommended for programming. If another person can be within the safeguarded space when in Manual Mode, an additional device can be integrated and configured for the additional person's use.

Switching	To switch between modes, in the Right Header, select the profile icon to display the Mode
Modes	Section.

- Automatic indicates the operational mode of the robot is set to Automatic.
- Manual indicates the operational mode of the robot is set to Manual.

PolyScope X is automatically in Manual Mode when the Safety I/O configuration with Three-Position Enabling Device is enabled.

# 15. Transportation

#### Description

Only transport the robot in its original packaging. Save the packaging material in a dry place if you want to move the robot later.

When moving the robot from its packaging to the installation space, hold both tubes of the robot arm at the same time. Hold the robot in place until all mounting bolts are securely tightened at the base of the robot.

Lift the Control Box by its handle.



#### WARNING

Incorrect lifting techniques, or using improper lifting equipment, can lead to injury.

- Avoid overloading your back or other body parts when lifting the equipment.
- · Use proper lifting equipment.
- All regional and national lifting guidelines shall be followed.
- Make sure to mount the robot according to the instructions in Mechanical Interface.

NOTICE

If the robot is transported as an assembled application with any external equipment, the following applies:

- Transporting the robot without its original packaging will void all warranties from Universal Robots A/S.
- If the robot is transported attached to a 3rd-party application / installation, follow the recommendations for transporting the robot without the original transport packaging.

Disclaimer Universal Robots cannot be held responsible for any damage caused by transportation of the equipment. See the recommendations for transportation without packaging at: <u>universal-</u>robots.com/manuals

### **Description** Universal Robots always recommends transporting the robot in its original packaging. These recommendations are written to reduce unwanted vibrations in joints and brake systems and reduce joint rotation.

If the robot is transported without its original packaging, then please refer to the following guidelines:

- Fold the robot as much as possible do not transport the robot in the singularity position.
- Move the center of gravity in the robot as close to the base as possible.
- Secure each tube to a solid surface on two different points on the tube.
- Secure any attached end effector rigidly in 3 axes.

#### Transport



### 15.1. Teach Pendant Storage

Description

The operator needs to have a clear understanding about what the e-Stop on the Teach Pendant affects when pressed. For example there can be confusion with a multi-robot installation. It should be made clear if the e-Stop on the Teach Pendant stops the whole installation or only its connected robot.

If there could be confusion, store the Teach Pendant such that the e-Stop button is not visible or usable.

# 16. Maintenance and Repair

#### Description

Any maintenance work, inspection and calibration shall be conducted in compliance with all safety instructions in this manual, the UR Service Manual, and according to local requirements. Repair work shall be done by Universal Robots. Client designated, trained individuals can do repair work, provided they follow the Service Manual.

#### Safety for Maintenance

The purpose of maintenance and repair is to ensure the system is kept functioning as expected. When working on the robot arm or control box, you must observe the procedures and



warnings below.

#### WARNING

Failure to adhere to any of the safety practices, listed below, can result in injury.

- Unplug the main power cable from the bottom of the Control Box to ensure that it is completely unpowered. Power off any other source of energy connected to the robot arm or Control Box. Take necessary precautions to prevent other persons from powering on the system during the repair period.
- · Check the earth connection before re-powering the system.
- Observe ESD regulations when parts of the robot arm or Control Box are disassembled.
- Prevent water and dust from entering the robot arm or Control Box.

Safety for Maintenance

#### WARNING

Failure to leave space to accommodate the Control Box with the door fully open can lead to injury.

• Provide at least 915 mm of space to enable the Control Box door to open fully, providing access for servicing.



#### WARNING: ELECTRICITY

Disassembling the Control Box power supply too quickly after switching off, can result in injury due to electrical hazards.

 Avoid disassembling the power supply inside the Control Box, as high voltages (up to 600 V) can be present inside these power supplies for several hours after the Control Box has been switched off.

After troubleshooting, maintenance, and repair work, ensure that safety requirements are fulfilled. Adhere to national or regional work safety regulations. The correct functioning of all safety function settings shall also be tested and validated.

LockoutUR robots can be de-energized and locked in the de-energized state. This is to controlTagouthazardous energy due to tasks associated with installation, maintenance or repair of the<br/>robot, robot application or robot cell.

To perform "Lockout" or "control of hazardous energy" of the power to the robot, you can use a power plug lock to prevent the power cord from being reattached to the Control Box, for example Brady 148081 Plug Lockout for IEC.



#### WARNING: ELECTRICITY

Exposure to hazardous energy or the release of contained hazardous energy can result in electrical shock and serious injury.

• Use a power plug lockout to prevent the power cord from being reattached to the control box. For example see Brady 148081 Plug Lockout for IEC plug or equivalent.

### 16.1. Testing Stopping Performance

#### Description

Test periodically to determine if stopping performance is degraded. Increased stopping times can require safeguarding to be modified, possibly with changes to the installation. If stop time and/or stop distance safety functions are used and are the basis of the risk reduction strategy, no monitoring or testing of stopping performance is required. The robot does continuous monitoring.

### 16.2. Robot Arm Cleaning and Inspection

Description As part of regular maintenance the robot arm can be cleaned, in accordance with the recommendations in this manual and local requirements. Cleaning To address the dust, dirt, or oil on the robot arm and/or Teach Pendant, simply use a cloth Methods alongside one of the cleaning agents provided below. Surface Preparation: Before applying the below solutions, surfaces may need to be prepared by removing any loose dirt or debris. Cleaning agents: Water 70% Isopropyl alcohol • 10% Ethanol alcohol 10% Naphtha (Use to remove grease.) Application: The solution is typically applied to the surface that needs cleaning using a spray bottle, brush, sponge, or cloth. It can be applied directly or diluted further depending on the level of contamination and the type of surface being cleaned. Agitation: For stubborn stains or heavily soiled areas, the solution may be agitated using a brush, scrubber, or other mechanical means to help loosen the contaminants.

**Dwell Time**: If necessary, the solution is allowed to dwell on the surface for a up to 5 minutes to penetrate and dissolve the contaminants effectively.

**Rinsing**: After the dwell time, the surface is typically rinsed thoroughly with water to remove the dissolved contaminants and any remaining cleaning agent residue. It's essential to ensure thorough rinsing to prevent any residue from causing damage or posing a safety hazard.

Drying: Finally, the cleaned surface may be left to air dry or dried using towels.



WARNING

DO NOT USE BLEACH in any diluted cleaning solution.



#### WARNING

Grease is an irritant and can cause an allergic reaction. Contact, inhalation or ingestion can cause illness or injury. To prevent illness or injury, adhere to the following:

- PREPARATION:
  - Ensure that the area is well ventilated.
  - Have no food or beverages around the robot and cleaning agents.
  - Ensure that an eye wash station is nearby.
  - Gather the required PPE (gloves, eye protection)
- WEAR :
  - Protective gloves: Oil resistant gloves (Nitrile) impermeable and resistant to product.
  - Eye protection is recommended to prevent accidental contact of grease with eyes.
- DO NOT INGEST.
- In the event of
  - contact with skin, wash with water and a mild cleaning agent
  - a skin reaction, get medical attention
  - contact with the eyes, use an eyewash station, get medical attention.
  - inhalation of vapors or ingestion of grease, get medical attention
- After grease work
  - clean contaminated work surfaces.
  - dispose responsibly of any used rags or paper used for cleaning.
- Contact with children and animals is prohibited.

Robot Arm Inspection Plan The table below is a checklist of the type of inspections recommended by Universal Robots. Perform inspections regularly as advised in the table. Any referenced parts found to be in an unacceptable state must be rectified or replaced.

Inspection action type			Timeframe		
			Monthly	Biannually	Annually
1	Check flat rings	V		X	
2	Check robot cable	V		X	
3	Check robot cable connection	V		X	
4	Check Robot Arm mounting bolts *	F	X		
5	Check Tool mounting bolts *	F	X		
6	Round Sling	F			X

j

Robot Arm

Inspection

Plan





Robot Arm Inspection Plan

- 1. Move the Robot Arm to ZERO position, if possible.
- 2. Turn off and disconnect the power cable from Control Box.
  - 3. Inspect the cable between Control Box and Robot Arm for any damage.
  - 4. Check the base mounting bolts are properly tightened.
  - 5. Check the tool flange bolts are properly tightened.
  - 6. Inspect the flat rings for wear and damage.
    - Replace the flat rings if they are worn out or damaged.



#### NOTICE

If any damage is observed on a robot within the warranty period, contact the distributor where the robot was purchased.

#### Inspection

- 1. Unmount any tool/s or attachment/s or set the TCP/Payload/CoG according to tool specifications.
- 2. To move the robot arm in Freedrive:
  - On a 3PE Teach Pendant, rapidly light-press, release, light-press again and keep holding the 3PE button in this position.



Power button

3PE button

3. Pull/Push the robot to a horizontally elongated position and release.



4. Verify the robot arm can maintain the position without support and without activating Freedrive.

# 17. Disposal and Environment

### **Description** Universal Robots robots must be disposed of in accordance with the applicable national laws, regulations and standards. this responsibility rests with the owner of the robot.

UR robots are produced in compliance with restricted use of hazardous substances to protect the environment; as defined by the European RoHS directive 2011/65/EU. If robots (robot arm, Control Box, Teach Pendant) are returned to Universal Robots Denmark, then the disposal is arranged by Universal Robots A/S.

The disposal fee for UR robots sold on the Danish market is prepaid to DPA-system by Universal Robots A/S. Importers in countries covered by the European WEEE Directive 2012/19/EU must make their own registration to the national WEEE register of their country. The fee is typically less than 1€/robot.

You can find a list of national registers here: <u>https://www.ewrn.org/national-registers</u>. Search for Global Compliance here: <u>https://www.universal-robots.com/download</u>.

Substances in	
the UR robot	

#### Robot arm

- Tubes, Base Flange, Tool mounting bracket: Anodized aluminum
- · Joint housings: Powder coated aluminum
- Black band sealing rings: AEM rubber
  - additional slip ring under black band: moulded black plastic
- Endcaps/ lids: PC/ASA Plastic
- Minor mechanical components e.g. screws, nuts, spacers (steel, brass, and plastic)
- Wire bundles with copper wires and minor mechanical components e.g. screws, nuts, spacers (steel, brass, and plastic)

#### Robot arm joints (internal)

- Gears: Steel and grease (detailed in the Service Manual)
- · Motors: Iron core with copper wires
- Wire bundles with copper wires, PCB's, various electronic components and minor mechanical components
- Joint seals and O-rings contain a small amount of PFAS which is a compound within PTFE (commonly known as Teflon<sup>TM</sup>).
- Grease: synthetic + mineral oil with a thickener of either lithium complex soap or Urea. Contains molybdenum.
  - Depending on model and date of production, the color of the grease could be yellow, magenta, dark pink, red, green.
  - The Service Manual details the handling precautions and Grease Safety Data Sheets

#### Control box

- Cabinet (enclosure): Powder coated steel
  - Standard Control Box
- Aluminum sheet metal housing (internal to the cabinet). This is also the housing of the OEM controller.
  - Standard Control Box and OEM controller.
- Wire bundles with copper wires, PCB's, various electronic components, plastic connectors, and minor mechanical components e.g. screws, nuts, spacers (steel, brass, and plastic)
- A lithium battery is mounted to a PCB. See the Service Manual for how to remove.

# 18. Declarations and Certifications

Delete this text and replace it with your own content.



## 18.1. Declaration of Incorporation (original)

### IR **UNIVERSAL ROBOTS**

EU Declaration of Incorporation (DOI) (in accordance with 2006/42/EC Annex II B)

EU Declaration of	of Incorporation (DC	I) (in accordance with 2006/42/EC Annex II	B) original: EN	
Manufacturer:		Person in the Community Authorized to Compile the Technical File:		
Universal Robots A/S Energivej 51 DK-5260 Odense S Denmark		David Brandt Technology Officer, R&D Universal Robots A/S, Energivej 51, DK-5260 Odense S		
Description and	d Identification of th	ne Partly-Completed Machine(s):		
Product and Function:	Industrial robot multi- pendant. Function is effector, intended us	purpose multi-axis manipulator with contro determined by the completed machine se and application program).	l box & with or without a 3PE teach (robot application or cell with end- NOTE:	
Model: Serial Number:	UR15: Below cited standards and this declaration include: Starting 2025 6 8 00002 and higher year			
Incorporation:	Universal Robots UR machine (robot appli Directive and other a	15 shall only be put into service upon beir cation or robot cell), which conforms with pplicable Directives.	ng integrated into a final complete the provisions of the Machinery	
<b>It is declared tha</b> When this partly co completed machin	t <b>the above products</b> completed machine is inte ne fulfiling all applicable [	fulfil, for what is supplied, the following grated and becomes a complete machine, t Directives, applying the CE mark and providir	<b>directives as detailed below:</b> he integrator is responsible for the g the Declaration of Conformity (DOC).	
I. Machinery Directive 2006/42/EC         The following essential requirements have been fulfilled:         1.1.2, 1.1.3, 1.1.5           1.1.6, 1.2.1, 1.2.4.3, 1.2.5, 1.2.6, 1.3.1, 1.3.2, 1.3.4, 1.3.8.1, 1.3.9, 1.4.1 with 3PE TP, 1.5.1, 1.5.2, 1.5.4, 1.5.5, 1.5.6, 1.5.10, 1.6.3, 1.7.1.1, 1.7.2, 1.7.4, 1.7.4.1, 1.7.4.2, 2.2.1.1, 4.1.2.1, 4.1.2.3, 4.1.2.4 (sling), 4.1.3, 4.3.3, Annex VI.           It is declared that the relevant technical documentation has been compiled				
II I ow-voltage D	)irective 2014/35/FU	in accordance with Part B of Annex VI	l of the Machinery Directive.	
III. EMC Directiv	re 2014/30/EU	Reference the EWC Directive and the h	narmonized standards used below.	
Reference to the harmonized standards used, as referred to in Article 7(2) of the MD & LV Directives and Article 6 of the EMC Directive:				
(I) EN ISO 1021	8-1:2011	(I) EN ISO 13850:2015	(III) EN 61000-3-2:2019	
(I) EN ISO 1210	0:2010	(I) EN 60204-1:2018	(III) EN 61000-3-3:2013	
(I) EN ISO 1384	9-1:2023	(II) EN 60529:1991+A1:2000+A2:2013	(III) EN 61000-6-2:2019	
(I) EN ISO 13849-2:2012		(I) EN 60947-5-5:1997+A1:2005	(III) EN 61000-6-4:2019	
(I) EN ISU 13732-1:2008		+A11:2013+A2:2017	(II) EN 61140:2002/ A1:2006	
(I) ISO 9409-1:2	2004	(III) EN 60068-2-27:2008	(II) EN 61784-3:2010 [SIL2]	
<ul> <li>(I) ISO/TS 15066:2016 as applicable</li> <li>(III) EN 60068-2-1:2007</li> <li>(III) EN 60068-2-2:2007</li> </ul>		<ul> <li>(III) EN 60068-2-64:2008+A1:2019</li> <li>(II) EN 60320-1:2021</li> <li>(II) EN 60664-1:2007</li> </ul>	(III) EN 61326-3-1 2017 [Industrial locations SIL 2]	
The manufacturer, or his authorised representative, shall transmit relevant information about the partly completed machinery in response to a reasoned request by the national authorities.				

Approval of full quality assurance system by the notified body Bureau Veritas: ISO 9001 certificate #DK015892 and ISO 45001 certificate #DK015891.

Odense Denmark, 31 March 2025

Sher Mon Murtz

Roberta Nelson Shea, Global Technical Compliance Officer

Universal Robots A/S, Energivej 51, DK-5260 Odense S, Denmark CVR-nr. 29 13 80 60

Phone +45 8993 8989 Fax +45 3879 8989

info@universal-robots.com www.universal-robots.com

### 18.2. Declarations and Certificates

EU Declaration of I	ncorporation (DOI) (in accordance	with 2006/42/EC Annex II B)		
Manufacturer	Universal Robots A/S Energivej 51, DK-5260 Odense S Denmark			
Person in the Community Authorized to Compile the Technical File	David Brandt Technology Officer, R&D Universal Robots A/S, Energiv	David Brandt Technology Officer, R&D Universal Robots A/S, Energivej 25, DK-5260 Odense S		
Description and Identification c	f the Partially-Completed Machine(	5)		
Product and Function: Industrial robot multi-purpose multi-axis manipulator with contro with or without teach pendant Function is determined by the con machine (robot application or cell with end-effector, intended us application program).		multi-axis manipulator with control box & Function is determined by the completed cell with end-effector, intended use and		
Model :	UR15: Below cited certification	ns and this declaration include:		
	Note: This Declaration of Incorporati UR OEM Controller is used.	on is NOT applicable when the		
Serial Number:	Starting 20256800002 and hig year series 7=UR15	her		
Incorporation:	Universal Robots UR15 shall only be put into service upon being integrated into a final complete machine (robot application or robot cell), which conforms with the provisions of the Machinery Directive and other applicable Directives.			
It is declared that the above pro When this partly completed ma responsible for the completed r the Declaration of Conformity (	oducts fulfil, for what is supplied, the ochine is integrated and becomes a of machine fulfiling all applicable Direc DOC)	following directives as detailed below: complete machine, the integrator is tives, applying the CE mark and providing		
I. Machinery Directive 2006/42/EC	The following essential require 1.1.5, 1.1.6, 1.2.1, 1.2.4.3, 1.2 1.3.9, 1.4.1 with 3PE TP, 1.5.1 1.7.1.1, 1.7.2, 1.7.4, 1.7.4.1, 1 (sling), 4.1.3, 4.3.3, Annex VI. documentation has been comp VII of the Machinery Directive.	The following essential requirements have been fulfilled: 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.2.1, 1.2.4.3, 1.2.5, 1.2.6, 1.3.1, 1.3.2, 1.3.4, 1.3.8.1, 1.3.9, 1.4.1 with 3PE TP, 1.5.1, 1.5.2, 1.5.4, 1.5.5, 1.5.6, 1.5.10, 1.6.3, 1.7.1.1, 1.7.2, 1.7.4, 1.7.4.1, 1.7.4.2, 2.2.1.1, 4.1.2.1, 4.1.2.3, 4.1.2.4 (sling), 4.1.3, 4.3.3, Annex VI. It is declared that the relevant technical documentation has been compiled in accordance with Part B of Annex VII of the Machinery Directive.		
II. Low-voltage Directive 2014/35/EU III. EMC Directive 2014/30/EU	Reference the LVD and the ha Reference the EMC Directive a below.	Reference the LVD and the harmonized standards used below. Reference the EMC Directive and the harmonized standards used below.		
Deference to the hormoniation	tondordo upod po referred to in Arti	alo 7/2) of the MD 8 LV Directives or t		
Article 6 of the EMC Directive:	tandards used, as referred to in Arth	cie 7(2) of the MD & LV Directives and		
(I) EN ISO 10218-1:2011 (I) EN ISO 12100:2010 (I) EN ISO 13849-1:2023 (I) EN ISO 13849-2:2012 (I) EN ISO 13732 1:2008	<ul> <li>(I) EN ISO 13850:2015 (I) EN</li> <li>60204-1:2018 (II) EN</li> <li>60529:1991+A1:2000+A2:2013</li> <li>(I) EN 60947-5-5:1997+A1:2005</li> <li>+A11:2013+A2:2017 (I) EN</li> </ul>	(III) EN 61000-3-2:2019 (III) EN 61000- 3-3:2013 (III) EN 61000-6-2:2019 (III) EN 61000-6-4:2019 (II) EN 61140:2002/ A1:2006		

Reference to other technical standards and technical specifications used:

60947-5-8:2020

(I) EN ISO 13732-1:2008

The manufacturer, or his authorised representative, shall transmit relevant information about the partly completed machinery in response to a reasoned request by the national authorities. Approval of full quality assurance system by the notified body Bureau Veritas: ISO 9001 certificate #DK015892 and ISO 45001 certificate #DK015891.

### 18.3. Certifications UR15

#### Description

Third party certification is voluntary. However, to provide the best service to robot integrators, Universal Robots chooses to certify its robots at the recognized test institutes listed below. You can find copies of all certificates in the chapter: Certificates.

These certifications are NOT valid for OEM installations.

#### Certification

EN ISO 10218-1 EN ISO 13849-1 CERTIFIED Www.tuv.com ID 0007000000	TÜV Rheinland	Certificates by TUV Rheinland to EN ISO 10218-1 and EN ISO 13849-1. TÜV Rheinland stands for safety and quality in virtually all areas of business and life. Founded 150 years ago, the company is one of the world's leading testing service providers.		
<b>TÜV</b> Rheinland®	TÜV Rheinland of North America	In Canada, the Canadian Electrical Code, CSA 22.1, Article 2-024 requires equipment to be certified by a testing organization approved by the Standards Council of Canada.		
	CHINA RoHS	Universal Robots e-Series robots conform to CHINA RoHS management methods for controlling pollution by electronic information products.		
DELTA	Delta	Universal Robots e-Series robots are performance tested by DELTA.		

Supplier Third Party Certification



Manufacturer
Test
Certification

R	Universal Robots	Universal Robots e-Series robots undergo continuous internal testing and end of line test procedures. UR testing processes undergo continuous review and improvement.

Declarations according to EU directives Although EU directives are relevant for Europe, some countries outside Europe recognize and/or require EU declarations. European directives are available on the official homepage: http://eur-lex.europa.eu.

According to the Machinery Directive, Universal Robots' robots are partly completed machines, as such a CE mark is not to be affixed.

You can find the Declaration of Incorporation (DOI) according to the Machinery Directive in the chapter: Declarations and Certificates.

### 18.4. Certificates UR15

**TÜV Rheinland** North America UL1740

	Certificate
Certificate no.	CU 72501652 0001
License Holder: Universal Robots A/: Energivej 51 5260 Odense S Denmark	Manufacturing Plant:         See additional page(s) for the listing of 3         factories
Report Number:	US25JQ7X 001 Client Reference: Roberta Nelson Shea
Certification acc. to:	UL 1740:2018 R8.23 CAN/CSA-Z434-14 + GI1 (R2019)
Product Information	on
Certified Product:	Industrial Robot
Model Designation:	UR15, UR20, UR30
Technical Data:	Rated Voltage:       a) AC 100-200V, 50/60Hz;         b) AC 200-240V, 50/60Hz         Rated Current:       a) 15A; b) 8A         Protection Class:       I
	Special Remarks: The following safety functions have been evaluated and determined to meet PLd Cat. 3 per EN ISO 13849-1:2015: 1 - Emergency Stop 2 - Safeguard Stop 3 - Joint Position Limit 4 - Joint Speed Limit 5 - Pose Limit 6 - Cartesian Speed Limit 7 - Force Limit 8 - Momentum Limit 9 - Power Limit 10 - Stopping Time Limit 11 - Stopping Time Limit 12 - System Emergency Stop Output 13 - Robot Moving Digital Output 14 - Robot Not Stopping Digital Output 15 - Reduced Mode Digital Output

**TUV Rheinland of North America, Inc.** 400 Beaver Brook Rd, Boxborough, MA 01719 Tel +1 (978) 266 9500, Fax +1 (978) 266-9992

www.tuv.com



#### China RoHS

#### Management Methods for Controlling Pollution by Electronic Information Products Product Declaration Table For Toxic or Hazardous Substances 麦1 有毒有害物质或元素名称及含量标识格式



Product/Part Name	Toxic and Hazardous Substances and Elements							
产品/ <b>部件名称</b>	<b>有毒有害物</b> 质或元素							
	铅 Lead (Pb)	<b>汞</b> Mercury (Hg)	镉 Cadmium (Cd)	<b>六价</b> Hexavalent Chromium (Cr+6)	<b>多溴</b> 联苯 Polybrominated biphenyls (PBB)	<b>多溴二苯</b> 醚 Polybrominated diphenyl ethers (PBDE)		
UR Robots 机器人:基本系统 UR3 / UR5 / UR10 / UR3e / UR5e /UR7e/ UR10e/UR12e/ UR16e / UR15/ UR20 / UR30	JR Robots 机器人:基本系统 JR3 / UR5 / UR10 / JR3e / UR5e / UR7e/ JR10e/UR12e/ JR16e / UR15/ JR20 / UR30							
<ul> <li>O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.</li> <li>O: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006规定的限量要求以下。</li> <li>X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.</li> <li>X: 表示该有毒有害物质至少在该部件的有均质材料中的含量超出SJ/T 11363-2006规定的限量要求以下。</li> <li>X: 表示该有毒有害物质至少在该部件的其一均质材料中的含量超出SJ/T 11363-2006规定的限量要求。</li> <li>(企业可在此处、根据实际情况对上表中打"X"的技术原因进行进一步说明。)</li> <li>Items below are wear-out items and therefore can have useful lives less than environmental use period:</li> <li>下列项目是损耗品,因而它们的有用环境寿命可能短于基本系统和可选项目的使用时间:</li> <li>Drives, Gaskets, Probes, Filters, Pins, Cables, Stiffener, Interfaces</li> </ul>								
电子驱动器, 垫圈, 探针, 过滤器, 别针, 缆绳, 加强筋, 接口 Refer to product manual for detailed conditions of use. 详细使用情况请阅读产品手册. Universal Robots encourages that all Electronic Information Products be recycled but does not assume responsibility or liability. Universal Robots 鼓励回收再循环利用所有的电子信息产品, 但 Universal Robots 不负任何责任或义务 To the maximum extent permitted by law, Customer shall be solely responsible for complying with, and shall otherwise assume all liabilities that may be imposed in connection with, any legal requirements adopted by any governmental authority related to the Management Methods for Controlling Pollution by Electronic Information Products (Ministry of Information Industry Order #39) of the Peoples Republic of China otherwise encouraging the recycle and use of electronic Information products. Customer shall defend, Indemnify and hold Universal Robots harmless from								

Controlling Pollution by Electronic Information Products (Ministry of Information Industry Order #39) of the Peoples Republic of China otherwise encouraging the recycle and use of electronic information products. Customer shall defend, indemnify and hold Universal Robots harmless from any damage, claim or liability relating thereto. At the time Customer desires to dispose of the Products, Customer shall refer to and comply with the specific waste management instructions and options set forth a twww.universal-robots.com/about-universal-robots/social-responsibility and www.teradyne.com/company/corporate-social-responsibility, as the same may be amended by Teradyne or Universal Robots.

# 19. Safety Functions Table

#### Description

Universal Robots safety functions and safety I/O are PLd Category 3 (ISO 13849-1), where each safety function has a PFH value less than 1.8E-07.

The PFH values are updated to include greater design flexibility for supply chain resilience.

For safety I/O the resulting safety function including the external device, or equipment, is determined by the overall architecture and the sum of all PFHs, including the UR robot safety function PFH.



#### NOTICE

The Safety Functions tables presented in this chapter are simplified. You can find the comprehensive versions of them here: https://www.universal-robots.com/support

169

SF1 Emergency Stop	Description	What happens?	Tolerance	Affects
(according to ISO 13850) See footnotes	Pressing the Estop PB on the pendant <sup>1</sup> or the External Estop (if using the Estop Safety Input) results in a Stop Cat 1 <sup>3</sup> with power removed from the robot actuators and the tool I/O. Command <sup>1</sup> all joints to stop and upon all joints coming to a monitored standstill state, power is	Category 1		Robot
	removed. For the integrated functional safety rating with an external safety- related control system or an external emergency stop device that is connected to the Emergency Stop input, add the PFH of this safety- related input to the PFH of this safety function's PFH value (less than 1.8E-07).	stop (IEC 60204-1)		including robot tool I/O

	Description	What happens?	Tolerance	Affects	
ə to 3-1)	This safety function is initiated by an external protective device using safety inputs that initiate a Cat 2 stop <sup>3</sup> . The tool I/O are unaffected by the safeguard stop. Various configurations are provided. If an enabling device is connected, it's possible to configure the safeguard stop to function in automatic mode ONLY. See the Stop Time and Stop Distance Safety Functions <sup>4</sup> . For the functional safety of the complete integrated safety function, add the PFH of the external protective device to the PFH of the Safeguard Stop.	Category 2 stop (IEC 60204-1) SS2 stop (as described in IEC 61800- 5-2)		Robot	

Joint	Description	What happens?	Tolerance	Affects
on soft	Sets upper and lower limits for the allowed joint positions.	Will not allow motion to		
SOIL	Stopping time and distance is not a considered as the limit(s)	exceed any limit settings.		
-1)	will not be violated. Each joint can have its own limits. Directly	Speed could be reduced		loint
	limits the set of allowed joint positions that the joints can move	so motion will not exceed	5°	(oach)
	within. It is set in the safety part of the User Interface. It is a	any limit. A robot stop will		(eacil)
	means of safety-rated soft axis limiting and space limiting,	be initiated to prevent		
	according to ISO 10218-1:2011, 5.12.3.	exceeding any limit.		

SF4 Joint	Description	What happens?	Tolerance	Affects
Speed	Sets an upper limit for the joint speed. Each joint can have its	Will not allow motion to		
	own limit. This safety function has the most influence on energy	exceed any limit settings.		
	transfer upon contact (clamping or transient). Directly limits the	Speed could be reduced		la int
	set of allowed joint speeds which the joints are allowed to	so motion will not exceed	1.15 °/s	Joint (coch)
	perform. It is set in the safety setup part of the User Interface.	any limit. A robot stop will		(each)
	Used to limit fast joint movements, e.g. risks related to	be initiated to prevent		
	singularities.	exceeding any limit.		

### Joint TorqueExceeding the internal joint torque limit (each joint) results in a Cat 03. This is not accessible to the user; it is a factoryLimitsetting. It is NOT shown as an e-Series safety function because there are no user settings and no user configurations.

SF5 Called	Description	What happens?	Tolerance	Affects
various names: Pose Limit, Tool Limit, Orientation Limit, Safety Planes, Safety Boundaries	Monitors the TCP Pose (position and orientation) and will prevent exceeding a safety plane or TCP Pose Limit. Multiple pose limits are possible (tool flange, elbow, and up to 2 configurable tool offset points with a radius) Orientation restricted by the deviation from the feature Z direction of the tool flange OR the TCP. This safety function consists of two parts. One is the safety planes for limiting the possible TCP positions. The second is the TCP orientation limit, which is entered as an allowed direction and a tolerance. This provides TCP and wrist inclusion/ exclusion zones due to the safety planes.	Will not allow motion to exceed any limit settings. Speed or torques could be reduced so motion will not exceed any limit. A robot stop will be initiated to prevent exceeding any limit. Will not allow motion to exceed any limit settings.	3° 40 mm	TCP Tool flange Elbow

SF6
Speed
Limit TCP
& Elbow

	Description	What happens?	Tolerance	Affects
5	Monitors the TCP and elbow speed to prevent exceeding a speed limit.	Will not allow motion to exceed any limit settings. Speed or torques could be reduced so motion will not exceed any limit. A robot stop will be initiated to prevent exceeding any limit. Will not allow motion to exceed any limit settings.	50 mm/s	ТСР

Description	What happens?	Tolerance	Affects
The Force Limit is the force exerted by the robot at the TCP (tool center point) and "elbow". The safety function continuously calculates the torques allowed for each joint to stay within the defined force limit for both the TCP & the elbow. The joints control their torque output to stay within the allowed torque range. This means that the forces at the TCP or elbow will stay within the defined force limit. When a monitored stop is initiated by the Force Limit SF, the robot will stop, then "back-off" to a position where the force limit was not exceeded. Then it will stop again.	Will not allow motion to exceed any limit settings. Speed or torques could be reduced so motion will not exceed any limit. A robot stop will be initiated to prevent exceeding any limit. Will not allow motion to exceed any limit settings.	25N	ТСР

SF8			-	
Momontum	Description	what happens?	lolerance	Affects
Limit	The momentum limit is	Will not allow motion to exceed any limit settings. Speed or		
	very useful for limiting	torques could be reduced so motion will not exceed any		
	transient impacts. The	limit. A robot stop will be initiated to prevent exceeding any	3kg m/s	Robot
	Momentum Limit affects	limit. Will not allow motion to exceed any limit settings.		
	the entire robot.			

SF9	Description	What happens?	Tolerance	Affects
Limit	This function monitors the mechanical work (sum of joint torques times joint angular speeds) performed by the robot, which also affects the current to the robot arm as well as the robot speed. This safety function dynamically limits the current/ torque but maintains the speed.	Dynamic limiting of the current/torque	10W	Robot

F10 UR	Description	What Happens	Affects
SF10 UR Robot Estop Output	Description         When configured for a Robot <estop> output and there is a robot stop, the dual outputs are LOW. If there is no Robot <estop> Stop initiated, dual outputs are high. Pulses are not used but they are tolerated.         These dual outputs change state for any external Estop that is connected to configurable safety inputs where this input is configured as an Emergency Stop input.         For the integrated functional safety rating with an external safety-related control system, add the PFH of this safety-related output to the PFH of the external safety-related control system.         For the Estop Output, validation is performed at the external equipment, as the UR output is an input to this external Estop safety function for external equipment.         NOTE: If the IMMI (Injection Moulding Machine Interface) is used, the UR Robot Estop output is NOT connected to the IMMI. There is no Estop output signal sent sent from the UR robot to the IMMI. This is a feature to prevent an unrecoverable</estop></estop>	What Happens Dual outputs go low in event of an Estop if configurable outputs are set	Affects External connection to logic and/or equipment
	stop condition.		

For SF11, SF12, SF13, SF14 and SF17: The integrated functional safety performance requires adding this PFH to the PFH of the external logic (if any) and its components.

SF11UR	Description	What Happens	Affects
Robot Moving: Digital Dutput	Whenever the robot is moving (motion underway), the dual digital outputs are LOW. Outputs are HIGH when no movement. The functional safety rating is for what is within the UR robot.	If configurable outputs are set: - When the robot is moving (motion underway), the dual digital outputs are LOW. - Outputs are HIGH when no movement.	External connection to logic and/or equipment

SF12 UR Behet Net	Description	Affects
stopping: Digital	When the robot is STOPPING (in process of stopping or in a stand-still condition) the dual digital outputs are HIGH. When outputs are LOW, robot is NOT in the process or stopping and NOT in a stand-still condition. The functional safety rating is for what is within the UB robot	External connection to logic and/or
output		equipment

SF13 UR Bebet	Description	Affects
Reduced : Digital Output	When the robot is using a reduced configuration (or reduced config is initiated), the dual digital outputs are LOW. See below. The functional safety rating is for what is within the UR robot. The integrated functional safety performance requires adding this PFH to the PFH of the external logic (if any) and its components.	External connection to logic and/or equipment

SF14 UR	Description				
Robot Not Reduced: Digital Output	Whenever the robot is NOT using a reduced configuration (or reduced config is not initiated), the dual digital outputs are LOW. The functional safety rating is for what is within the UR robot. The integrated functional safety performance requires adding this PFH to the PFH of the external logic (if any) and its components.				
SF15	Description	What happens?	Tolerances	Affects	
Time Limit	Real time monitoring of conditions such that the stopping time limit will not be exceeded. Robot speed is limited to ensure that the stop time limit is not exceeded. The stopping capability of the robot in the given motion(s) is continuously monitored to prevent motions that would exceed the stopping limit. If the time needed to stop the robot is at risk of exceeding the time limit, the speed of motion is reduced to ensure the limit is not exceeded. A robot stop will be initiated to prevent exceeding the limit. The safety function performs the same calculation of the stopping time for the given motion(s) and initiates a cat 0 stop if the stopping time limit will be or is exceeded.	Will not allow the actual stopping time to exceed the limit setting. Causes decrease in speed or a robot stop so as NOT to exceed the limit	50 ms	Robot	
SF16	Description	What happens?	Tolerances	Affects	
Stopping Distance Limit	Real time monitoring of conditions such that the stopping distance limit will not be exceeded. Robot speed is limited to ensure that the stop distance limit will not be exceeded. The stopping capability of the robot in the given motion(s) is continuously monitored to prevent motions that would exceed the stopping limit. If the time needed to stop the robot is at risk of exceeding the time limit, the speed of motion is reduced to ensure the limit is not exceeded. A robot stop will be initiated to prevent exceeding the limit. The safety function performs the same calculation of the	Will not allow the actual stopping time to exceed the limit setting. Causes decrease in speed or a robot stop so as NOT to exceed the limit	40 mm	Robot	

stopping distance for the given motion(s) and initiates a cat 0

stop if stopping time limit will be or is exceeded.

SF17 Safe Home Position "monitored position"

Description	What happens?	Tolerances	Affects
Safety function which monitors a safety rated output,			
such that it ensures that the output can only be	The "safe home output" can		External
activated when the robot is in the configured and	only be activated when the	170	connection to
monitored "safe home position".	robot is in the configured	1.7	logic and/or
A stop cat 0 is initiated if the output is activated when	"safe home position"		equipment
the robot is not in the configured position.			

Table 1 footnotes <sup>1</sup>Communications between the Teach Pendant, controller and within the robot (between joints) are SIL 2 for safety data, per IEC 61784-3.

<sup>2</sup>Estop validation: the pendant Estop pushbutton is evaluated within the pendant, then communicated<sup>1</sup> to the safety controller by SIL2 communications. To validate the pendant Estop functionality, press the Pendant Estop pushbutton and verify that an Estop results. This validates that the Estop is connected within the pendant, the estop functions as intended, and the pendant is connected to the controller.

<sup>3</sup>Stop Categories according to IEC 60204-1 (NFPA79). For the Estop, only stop category 0 and 1 are allowed according to IEC 60204-1.

- Stop Category 0 and 1 result in the removal of drive power, with stop cat 0 being IMMEDIATE and stop cat 1 being a controlled stop (e.g. decelerate to a stop then removal of drive power). With UR robots, a stop category 1 is a controlled stop where power is removed when a monitored standstill is detected.
- Stop Category 2 is a stop where drive power is NOT removed. Stop category 2 is defined in IEC 60204-1. Descriptions of STO, SS1 and SS2 are in IEC 61800-5-2. With UR robots, a stop category 2 maintains the trajectory, then retains power to the drives after stopping.

<sup>4</sup>It is recommended to use the UR Stop Time and Stop Distance Safety Functions. These limits should be used for your application stop time/ safety distance values.

### 19.1. Table 1a

Reduced SF	Description	Affects	
parameter settings change	The reduced configuration can be initiated by a safety plane/ boundary (starts at 2cm of the plane and reduced settings are achieved within 2cm of the plane) or by use of an input to initiate (will achieve reduced settings within 500ms). When the external connections are Low, Reduced is initiated. Reduced configuration means that ALL reduced limits are ACTIVE. Reduced is not a safety function, rather it is a state change affecting the settings of the following safety function limits: joint position, joint speed, TCP pose limit, TCP speed, TCP force, momentum, power, stopping time, and stopping distance. A reduced configuration is a means of parametrization of safety functions in accordance with ISO 13849-1. All parameter values need to be verified and validated as to whether they are appropriate for the robot application.	Robot	
Safeguard	Description	Affecto	
Reset	Description	Anects	
	When configured for Safeguard Reset and the external connections transition from low to high, the safeguard stop RESETS. Safety input to initiate a reset of safeguard stop safety function.	Robot	
3-Position	Description	Affects	
Enabling Device INPUT	<ul> <li>When the external Enabling Device connections are Low, a Safeguard Stop (SF2) is initiated.</li> <li>Recommendation: Use with a mode switch as a safety input. If a mode switch is not used and connected to the safety inputs, then the robot mode will be determined by the User Interface. If the User Interface is in: <ul> <li>"running mode", the enabling device will not be active.</li> <li>"programming mode", the enabling device will be active. It is possible to use password protection for changing the mode by the User Interface.</li> </ul> </li> </ul>	Robot	
Mode	Description	Affects	
switch INPUT	When the external connections are Low, Operation Mode (running/ automatic operation in automatic mode) is in effect. When High, mode is programming/ teach. Recommendation: Use with an enabling device, for example a UR e-Series Teach Pendant with an integrated 3-position enabling device. When in teach/program, initially both TCP speed and elbow speed will be limited to 250mm/s. The speed can manually be increased by using the pendant user interface "speed-slider", but upon activation of the enabling device, the speed limitation will reset to 250mm/s.	Robot	
Freedrive	Description	Affects	
INPUT	Recommendation: Use with 3PE TP and/or 3 Position Enabling Device INPUT. When Freedrive INPUT is		
	High, the robot will only enter Freedrive if the following conditions are satisfied:		
	3PE TP button is not pressed	Robot	
	3 Position Enabling Device INPUT either not configured or not pressed (INPUT Low)		

### 19.2. Table 2

#### Description

UR e-Series robots comply with ISO 10218-1:2011 and the applicable portions of ISO/TS 15066. It is important to note that most of ISO/TS 15066 is directed towards the integrator and not the robot manufacturer. ISO 10218-1:2011, clause 5.10 collaborative operation details 4 collaborative operation techniques as explained below. It is very important to understand that collaborative operation is of the APPLICATION when in AUTOMATIC mode.

Collaborative	Technique	Explanation	UR e-Series
Operation 2011 edition, clause 5.10.2	Safety-rated monitored stop	Stop condition where position is held at a standstill and is monitored as a safety function. Category 2 stop is permitted to auto reset. In the case of resetting and restarting operation after a safety -rated monitored stop, see ISO 10218-2 and ISO/TS 15066 as resumption shall not cause hazardous conditions.	UR robots' safeguard stop is a safety-rated monitored stop, See SF2 on page 1. It is likely, in the future, that "safety-rated monitored stop" will not be called a form of collaborative operation.

Collaborative	Technique	Explanation	UR e-Series
2011 edition, clause 5.10.3	Hand-guiding	This is essentially individual and direct personal control while the robot is in automatic mode. Hand guiding equipment shall be located close to the end-effector and shall have: • an Emergency Stop pushbutton • a 3-position enabling device • a safety-rated monitored stop function • a settable safety-rated monitored speed function	UR robots do not provide hand-guiding for collaborative operation. Hand-guided teach (free drive) is provided with UR robots but this is for programming in manual mode and not for collaborative operation in automatic mode.

Operation 2011 edition, clause 5.10.4       SSM is the robot maintaining a separation distance from any operator (human). This is done by monitoring of the distance between the robot system and intrusions to ensure that the MINIMUM PROTECTIVE DISTANCE is assured. Usually, this is accomplished using Sensitive Protective Equipment (SPE), where typically a safety laser scanner detects intrusion(s) towards the robot system. This SPE causes:       To facilitate SSM, UR robots have the capability switching between two sets of parameters for sait functions with configurable limits (normal and rec parameters for the limiting asafety functions; or         Speed and separation monitoring (SSM) safety functions       1. dynamic changing of the parameters for the limiting safety functions; or       To facilitate SSM, UR robots have the capability switching between two sets of parameters for sait functions with configurable limits (normal and rec stop condition.         Upon detection of the intrusion exiting the protective device's detection zone, the robot is permitted to:       2. a safety-rated monitored stop condition.       Safety function go the parameters for the intrusion exiting the protective device's detection zone, the robot is permitted to:         1. resume the "higher" normal safety function limits in the case of 1) above       1. resume operation in the
case of 2) above In the case of 2) 2), restarting operation after a safety -rated monitored stop, see ISO 10218-2

Collaborative Operation 2011 edition, clause 5.10.5

Technique	Explanation	UR e-Series
Power and force limiting (PFL) by inherent design or control	How to accomplish PFL is left to the robot manufacturer. The robot design and/or safety functions will limit the energy transfer from the robot to a person. If any parameter limit is exceeded, a robot stop happens. PFL applications require considering the ROBOT APPLICATION (including the end-effector and workpiece(s), so that any contact will not cause injury. The study performed evaluated pressures to the ONSET of pain, not injury. See Annex A. See ISO/TR 20218-1 End-effectors.	UR robots are power and force limiting robots specifically designed to enable collaborative applications where the robot could contact a person and cause no injury. UR robots have safety functions that can be used to limit motion, speed, momentum, force, power and more of the robot. These safety functions are used in the robot application to thereby lessen pressures and forces caused by the end-effector and workpiece(s).

Software Name: PolyScope X Software Version: 10.10 Document Version: 10.13.305



